



# User Manual

NovaCool Rear Door Heat Exchanger



# Content

## ***Part I. Introduction***.....6

Scope of Application .....	6
Copyright & Disclaimer .....	6
Quality Management & Certifications .....	6
Contact Information.....	6

## ***Part II. Safety Information***.....7

General Safety Warnings .....	7
Electrical Safety Precautions .....	8
Handling & Installation Safety .....	8
Operational & Maintenance Safety .....	8

## ***Part III. Product Overview***.....10

Product Specifications .....	10
Features and Capabilities .....	10
Product Part Number Matrix .....	11
Label Information .....	13
Product Dimensions .....	14
Components Layout.....	15
Typical Capacity .....	18

## ***Part IV. Tools, Unpacking and Installation***.....19

Tool list .....	19
Unpacking .....	20
Pre-Installation Checks .....	24
Floor Cut-Outs.....	24
Installation .....	25
Liquid Circuit Connections .....	32
Bottom Feed Instruction .....	32
Top Feed Instruction.....	41
Valve Installation .....	46

Actuator Installation.....	47
Electrical Connections .....	48
Power Panel Overview .....	48
Port Definition.....	49
Fuse Rating .....	51
Input Power Cord Connection .....	51
Network cable Connection .....	53
Commissioning Tool Connection (Option).....	54
Actuator Cable Connection .....	55
Leak Detection Rope Wiring .....	56
Room Temperature Sensor Installation.....	57
Capacity Sensor Installation .....	58
Flow and Temp Sensor VFS Installation .....	58
Power Cable Connection .....	58
Pressure and Temp Sensor RPS Installation.....	60
Power Cable Connection .....	60
<b>Part V. System Setup and Start-up.....</b>	<b>62</b>
Pre-Activation Checklist.....	62
Physical Inspection .....	62
Liquid Circuit Checks .....	62
Electrical and Control System Verification.....	62
Power-On Procedures .....	62
Power Supply Activation.....	62
System Initialization .....	62
Liquid Circuit Activation.....	62
Fan and Valve Operation Check .....	62
Initial Setup .....	63
Control Panel Configuration .....	63
<b>Part VI. Commission Tool Configuration.....</b>	<b>64</b>
Hardware Display.....	64
Parts Identification .....	64
System Status .....	65
Power Status.....	66
Selection Menu .....	66
Control – Metric Selection .....	67
Temperature Settings.....	67

Control – Fan .....	68
Control – Valve .....	69
Water Sensor Settings .....	69
Control- dP sensor .....	70
Alarm Settings .....	70
Factory Settings .....	71
Leakage Sensor Settings .....	71
Fan Replace .....	72
Preventive Maintenance Settings .....	73
IO - Status Analog .....	74
IO - Status Digital .....	74
Program Settings .....	74
Alarm Bypass Screen .....	75
Air In Sensor bypass Settings .....	75
Sensor Calibration .....	76
Network Settings .....	77
Date/Time Settings .....	78
Manual Testing .....	78
Alarms .....	79
Active Alarm - View .....	79
Active History .....	80
System Information .....	80
Modbus Register List .....	81
Web User Interface Configuration .....	87
Web Configuration .....	87
Web Access .....	87
Log on Web UI .....	87
Change Password .....	87
Home .....	88
Control settings .....	90
Factory setting .....	92
Leakage Sensor Settings .....	93
Water Sensor Settings .....	93
Program Control settings .....	94
Common settings .....	94
Network Settings .....	95
Date & Time settings .....	96

Manual Testing .....	97
IO Status .....	98
Alarm Settings .....	99
SNMP Module configuration .....	101
Default Access Details .....	101
Network Configuration.....	101
PLC and Modbus TCP Configuration.....	102
Web Page Access .....	102
Available Web Pages .....	103
Control Page .....	104
Factory Setting .....	105
Common setting page.....	106
Date & Time.....	106
Manual page.....	106
IO page.....	107
Alarm Setting page.....	108
Notification page .....	109
Sensor Calibration page.....	109
System Info page .....	109
<b>Part VII. Maintenance and Troubleshooting .....</b>	<b>110</b>
Weekly Checks .....	110
Monthly Maintenance .....	110
Quarterly Checks .....	110
Annual Maintenance .....	110
Cleaning and Water Quality Management.....	111
Cleaning Guidelines .....	111
Water Quality Management.....	111
Alarms & Trouble shooting .....	112
Faulty Modular Replacement .....	124
Fan Modular Replacement.....	124
Control Box Replacement Guide.....	127
Temperature Sensor Replacement Guide.....	129
Differential Pressure Sensor Replacement Guide .....	133
Disconnect the network cable .....	135
LED Light Replacement Guide.....	138
Fan Cover Replacement Guide.....	141
Coil Replacement Guide .....	144

# Part I. Introduction

## Scope of Application

This manual provides comprehensive guidance on the installation, operation, maintenance, and troubleshooting of the **NovaCool RDHx**. It is intended for use by qualified technicians, data center operators, and maintenance personnel. Following this manual ensures optimal performance, reliability, and safety of the equipment.

This product is designed for **indoor** use in data centers and IT environments. It provides **efficient cooling** for rack-mounted IT equipment, helping to maintain optimal operating conditions.

## Copyright & Disclaimer

Copyright © 2025 INOVA LLC. All rights reserved.

This document is proprietary information of INOVA DC LLC. and is intended for authorized use only.

This document is proprietary information of INOVA DC LLC. and is intended for authorized use only.

Unauthorized reproduction, distribution, or modification is prohibited.

Specifications and information in this manual are subject to change without prior notice.

INOVA DC LLC. is not responsible for damages resulting from improper use, modification, or non-compliance with this manual.

## Quality Management & Certifications

The **NovaCool RDHx** is designed and manufactured in compliance with international quality and safety standards:

- ✧ **Quality Certification:** ISO 9001
- ✧ **Safety Compliance:** UL62368-1
- ✧ **Environmental Compliance:** RoHS, REACH
- ✧ **Electrical Safety:** CE, FCC Part 15

## Contact Information

For technical support, warranty claims, or general inquiries, please contact:

INOVA DC LLC.

- ✧ **Website:** [www.inovadc.com](http://www.inovadc.com)
- ✧ **Email:** [sales@inovadc.com](mailto:sales@inovadc.com)
- ✧ **Address:** 8 The Green, Suite R in the City of Dover. Delaware. Zip code 19901.

## Part II. Safety Information

### General Safety Warnings

Read this manual thoroughly before installation, operation, or maintenance.

This equipment must be installed and serviced only by trained and qualified personnel.

Failure to follow safety precautions may result in serious **injury, electric shock, or equipment damage**.

Keep this manual **accessible** for future reference.

This equipment is intended for industrial environments only and must not be used in areas **accessible** to children.

 The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.

 This symbol alerts users to potential personal injury hazards.

 Obey all safety messages that follow this symbol to avoid possible injury or death.

The following blocks will appear again in the following chapters. Please pay special attention to those safety notices.

#### **DANGER**

Danger indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury, or equipment damage.

#### **WARNING**

Warning indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury, or equipment damage.

#### **CAUTION**

Caution indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury, or equipment damage.

#### **NOTICE**

Notice addresses practices not related to physical injury including certain environmental hazards, potential damage, or loss of data.

## Electrical Safety Precautions

- ✧ This product **must be properly grounded** before operation.
- ✧ The unit uses a plug-type disconnect device. Ensure the output sockets remain easily accessible at all times.
- ✧ **Disconnect all power sources** before performing power control box maintenance.
- ✧ Do not operate the unit with damaged power cords, loose connections, or exposed wiring.
- ✧ Power cables should be routed safely to avoid **tripping hazards or mechanical damage**.
- ✧ Fuses must only be replaced by qualified personnel using the specified ratings for detailed instructions, please refer to the maintenance guide.
- ✧ If dual power inputs are provided, ensure that both inputs are **properly isolated** before servicing.
- ✧ This unit should be installed according to local electrical regulations.

## Handling & Installation Safety

- ✧ **Heavy Equipment:** This unit may weigh over **200 kg/440 lbs**. Use proper lifting equipment or a team of at least **four trained people** for handling.
- ✧ **Positioning:** The unit must be installed **vertically** on a stable, level floor.
- ✧ **Tipping hazards:** In handling or removal, ensure the equipment is lifted from the bottom to avoid toppling. When the NovaCool RDHx is installed in an empty rack, the counterweight should be appropriately adjusted to prevent tipping due to an unstable center of gravity.
- ✧ Avoid water exposure: The unit must not be exposed to excessive humidity, condensation, or liquid spills.
- ✧ **Shock & Vibration:** Avoid installation in high-vibration areas to **prevent structural damage**.

## Operational & Maintenance Safety

- ✧ This product is intended for use in data centers. The door cover is not designed to be opened by non-professional personnel and should only be accessed by qualified staff using a dedicated key for maintenance work
- ✧ **Moving Parts:** The unit contains —keep hands, clothing, and tools clear during operation.
- ✧ **Temperature Hazards:** Some parts may become hot during operation—avoid direct contact.
- ✧ Cooling System Precautions:
  - ✧ Always check for leaks or abnormal pressure fluctuations in the water-cooling system.
    - Use only **manufacturer-approved hoses and fittings**.
    - Do not exceed the **maximum water pressure** of 64.3 psi/ 4.5 bar.

- ❖ Emergency Shutdown:
  - In case of system failure, immediately power off and disconnect the unit.
  - Do not attempt repairs without proper authorization and tools.
- ❖ Personal Protective Equipment (PPE): Always wear appropriate gloves, eye protection, and safety shoes when handling components.

# Part III. Product Overview

## Product Specifications

The **NovaCool RDHx** is a high-efficiency RDHx designed to provide superior cooling for data centers and high-density IT environments. The following are the key specifications:

- ✧ **Maximum Cooling Capacity:** Up to 85kW @ 20°C inlet water temperature, 24°C air supply.
- ✧ **Available Sizes:** 42U, 48U, 52U, with widths of 600mm and 800mm.
- ✧ **Power Supply:** Dual power feed with built-in Automatic Transfer Switch (ATS).
- ✧ **Fan Type:** Hot-swappable EC fans, N+1 redundant.
- ✧ **Monitoring:** Real-time power supply health, cooling capacity, water temperature, pressure, and flow rate monitoring.
- ✧ **Connectivity:** Ethernet, Web Interface, Modbus TCP/IP, BACnet.
- ✧ **Leak Detection:** Standard leakage sensor with automatic shutoff to prevent water damage.

## Features and Capabilities

The **NovaCool RDHx** incorporates state-of-the-art cooling technology, offering superior thermal management and operational efficiency. The key features include:

- ✧ **High-Efficiency Heat Exchanger:** Designed with a proprietary heat exchanger for optimal thermal transfer and maximum cooling efficiency.
- ✧ **Optimized Energy Efficiency:** Capable of utilizing high-temperature inlet water to enhance free cooling capabilities, significantly reducing energy consumption and operational costs.
- ✧ **Intelligent Fan and Valve Control:** Automatic dynamic adjustment based on real-time load conditions to ensure precise cooling regulation.
- ✧ **Seamless Maintenance and Serviceability:** Tool-free, hot-swappable fans and controllers allow for effortless servicing without disrupting operations.
- ✧ **Enhanced Safety Mechanisms:** Integrated leakage detection and dual power supply redundancy improve system reliability and prevent unexpected failures.
- ✧ **Flexible and Modular Design:** Compatible with multiple rack sizes, enabling seamless integration into diverse data center environments.

## Product Part Number Matrix

The complete series of products consists of the door and frame, piping kit, valve kit, commissioning tools, and sensors. Table 1 is a list of standard products that can meet the requirements of most application scenarios. Customers should first select the appropriate model of the door. Then, based on the water and electrical connection points, choose the corresponding water pipes and electrical cables. Depending on performance requirements and regional considerations, different valves and actuators can be selected. Additionally, commissioning tools and other accessories can be configured as needed.

**Table 1. Standard Product List**

Part Number	Short Description
NC1-642WL	42UX600 Standard Rear Door, Left-hand open. Including Package
NC1-648WL	48UX600 Standard Rear Door, Left-hand open. Including Package
NC1-842WL	42UX800 Standard Rear Door, Left-hand open. Including Package
NC1-848WL	48UX800 Standard Rear Door, Left-hand open. Including Package
NC1-642WR	42UX600 Standard Rear Door, Right-hand open
NC1-648WR	48UX600 Standard Rear Door, Right-hand open
NC1-842WR	42UX800 Standard Rear Door, Right-hand open
NC1-848WR	48UX800 Standard Rear Door, Right-hand open
NC1-P38BSPT	Pair of Bottom entry pipes with BSP connector
NC1-P38NPT	Pair of Bottom entry pipes with NPT connector
NC1-P20BSPT	Pair of Top entry pipes with BSP connector
NC1-P20NPT	Pair of Top entry pipes with NPT connector
NC1-C19C20UL35	Feed A and B power cord, top feed. US Region
NC1-C19C20UL60	Feed A and B power cord, bottom feed. US Region
NC1-C19C20VDE35	Feed A and B power cord, top feed. EU Region
NC1-C19C20VDE60	Feed A and B power cord, bottom feed. EU Region
NC1-ACTZTU	Actuator Commissioning Tool
NC1-ACT	Actuator
NC1-VLV63NPT	Valve 6.3m <sup>3</sup> /h, with 1" NPT
NC1-VLV100NPT	Valve 10m <sup>3</sup> /h, with 1" NPT
NC1-VLV63BSPT	Valve 6.3m <sup>3</sup> /h, with 1" BSP
NC1-VLV100BSPT	Valve 10m <sup>3</sup> /h, with 1" BSP
NC1-3VLV63NPT	Valve 6.3m <sup>3</sup> /h, with 1" NPT
NC1-3VLV63BSPT	Valve 6.3m <sup>3</sup> /h, with 1" BSP
NC1-652HW	600mmX52U Adaptor
NC1-852HW	800mmX52U Adaptor
NC1-OPHMI	HMI, commissioning tool.
NC1-SEALANT	Sealant
NC1-VFSN	VFS kits
NC1-VFSB	VFS kits
NC1-RPSN	RPS kits with NPT connector
NC1-RPSB	RPS kits with BSP connector

If none of the products in the above table are suitable, please contact sales to confirm compatibility and feasibility. And below is the part number matrix for customized parts.

**Table 2. Customized Door Part Matrix**

NC1	-	W	HH	C	A	BB	CC
Product Line	-	Width	Height	Color	Open Direction	Preserved Configuration	Preserved Configuration
NovaCool RDHx		6-600mm	42-42U	B-Black	L-Left Hinge	For software customization	For other parts configuration
		...	45-45U	W-White	R-Right Hinge	Two digits, could be number or characters	Two digits, could be number or characters
		8-800mm	48-48U	G-Gray			
				S-Steel			DC-DP sensor
				M-Mix			EC-Serial HMI
							FC-DP sensor + Serial HMI
							GC-DP sensor + SIG
							XC-SIG+Network HMI+DP sensor
							YC-SIG+Network HMI
							ZC-SIG
							The first C is for SIG/HMI/DP sensor config
							The second C is preserved for other mechanical parts configuration. Take an example, customer wants to add some connection bracket to their cabinet, this digit represents the customized bracket.... Customer wants to add some logo or brand badge on the door, or remove the green thunder on the front panel, etc.

Note:

For most of cases, CC are not included in the PN.

From Dec of 25, BB upgrade to 02, due to engineering enhancements and updates.

**Table 3. Customized Component Number Matrix**


NCC	-	X	#####*
Product Line- Customized Components	-	M-Metal	00001~99999
		P-Pipes	00001~99999
		D-Special Doors	00001~99999
		T-Others	00001~99999

Note:

\*Since the product needs to be compatible with the customer's on-site environment and equipment, there are often requirements for additional custom-made parts such as sheet metal covers, piping, and other special structural components. These custom parts will be numbered sequentially, starting from 00001 and continuing up to 99999.

## Label Information

Below is the product label information, which includes the common information of product description in short, rated voltage and current, and cooling capacity. And on top of it is the product part number and product serial number, which is different for each unit.



**Figure 1. Typical Product Label**

## Product Dimensions




Figure 2. Schematic Diagram

Table 4. Product Dimensions Table

Model		Height (Y) mm(")	Width (X) mm(")	Depth mm(")	Number of Fans	Dry Weight kg(lbs)	Wet Weight kg(lbs)
42U/45U	600W	2050(80.7)	598(23.5)	380(14.96)	5	152(334)	165(363)
	700W		698(27.5)	380(14.96)	5	154(339)	167(368)
	800W		798(31.4)	380(14.96)	5	156(343)	169(372)
48U/52U	600W	2330(91.7)	598(23.5)	380(14.96)	6	170(374)	185(407)
	700W		698(27.5)	380(14.96)	6	178(392)	193(425)
	800W		798(31.4)	380(14.96)	6	186(410)	204(449)

(All models are available in both left- and right-hinged configurations.)

## Components Layout





Figure 3. Components Layout (Front)



**Figure 4. Component Layout (Rear)**




Figure 5. Component Layout (Rear)

## Typical Capacity

The cooling capacity of **NovaCool RDHx** varies depending on environmental parameters, inlet water temperature, and IT load conditions. The following table presents typical performance benchmarks:

Table 5. Capacity Under Typical Working Conditions


Inlet water temp	Air temp in cabinet	Cooling capacity		
		48U 800W	48U 600W	42U 600W/800W
°C	°C	kW		
20/14	55	86/100	84/98	82/97
	50	73/90	71/87	69/85
	45	60/77	58/74	56/72
	40	45/63	44/61	42/59

(Performance values are based on laboratory testing and may vary under real-world conditions.)

## Part IV. Tools, Unpacking and Installation

### Tool list


\*Tools are not provided.




Steel strip scissors




Electric screwdriver




Utility knife



Scissors




T30 Torx screwdriver bit




5mm Ball-End hex bit



PH2 Phillips screwdriver bit




Level




Tape measure



Adjustable open-end wrench 15" x2




1/8" Slotted Screwdriver



Lifting crowbar



Ladder



Adjustable open-end wrench  
18" x1

Figure 6. Tool List

## Unpacking

### ⚠ WARNING

This product is heavy. Follow all local safety regulations to ensure personnel safety during disassembly, installation, and transportation. If lifting equipment is not available, a minimum of six people is required for manual handling.

***Failure to follow these instructions can result in serious injury, death or equipment damage.***

- Remove the steel strapping and all metal fixing brackets.




Figure 7. Unpacking

- Dismantle wooden box.





Figure 8. Unpacking

➤ Remove the top RDHx, the cartons, and the front and rear EPEs.


(Note: If there is only one set in the packaging, please skip this step.)




**Figure 9. Remove Top RDHx**

➤ Remove the M6×12 Phillips head screws at the bottom, a total of 6 places. And remove the brackets.

(Note: If there is only one set in the packaging, please skip this step.)




**Figure 10. Remove the Brackets**



**Table 7. Material List**

Item	Name	Comments	QTY
1	RDHx	/	1
2	Blue Pipe Kit	/	1
3	Mounting Accessories Kit	Includes: 1. Mounting accessories 2. Power Cords 3. Belimo Ball Valve 4. VFS Sensor (Optional) 5. RPS Sensor (Optional) 6. Fernox LS-X Sealant (Optional)	1
4	Red Pipe Kit	/	1
5	Commissioning Tool	Optional	1



**Table 8. Material List**

Item	Name	Comments	QTY
1	RDHx	/	2
2	Blue Pipe Kit	/	2
3	Mounting Accessories Kit	Includes: 1. Mounting accessories 2. Power Cords 3. Belimo Ball Valve 4. VFS Sensor (Optional) 5. RPS Sensor (Optional) 6. Ferno LS-X Sealant (Optional)	2
4	Red Pipe Kit	/	2
5	Commissioning Tool	Optional	1

## Pre-Installation Checks

- Ensure that the floor can take the weight of the unit.
- Ensure any MAP tiles or grommets are installed, or that any floor tiles are cut as appropriate.
- Check that the working area is free of hazards.
- The rack front door should be correctly closed to avoid damage when tipping.

## Floor Cut-Outs




Figure 11. Floor Cut-Outs

- When using bottom-fed RDHx hoses, they must pass through designated openings on the floor.
- A **150mm x 120mm** slot should be cut on the floor to accommodate the hoses.
- The hoses may move vertically within the slot as the RDHx unit is opened and closed. Ensure that all cut edges are smooth and free of sharp surfaces to prevent potential damage to the hoses.
- Additional holes may also be cut within the rack footprint to allow network cables etc. to pass through. Reference should be made to the positions of cable trays within the rack when cutting access holes.

## Installation

### NOTICE

- Do not place the RDHx with the fan side facing downward on the ground.
- Ensure the door lock is fully engaged during transportation.
- If fan removal is required to reduce the door weight for transportation, the fan module that includes the door lock must remain installed.
- When lifting the RDHx from a horizontal to a vertical position, ensure the door frame contacts the ground first. Contact of the fan assembly with the ground may result in deformation or damage.

➤ Install the fixing brackets with the Torx Screws. Torque is 10 N·m.






Figure 12. Fixing Bracket Installation

- Use a tape measure to ensure dimensions are correct.



**Figure 13. Fixing Bracket Position**

- Apply the sealing strip.



**Figure 14. Sealing Strip Paste**

- Remove the top and bottom RDHx brackets.




Figure 15. Brackets Removal

- A team of four people is required to transport and lift the RDHx from this side.




Figure 16. Door Lift-up

- Position the door close to the cabinet and ensure proper alignment. Use a pry bar if necessary.




Figure 17. Door Against to Cabinet

Pry Bar

- **For Empty Cabinet:** Stand inside the cabinet, insert the Scorpio Bracket into the slot on the RDHx, slide it to align with the L bracket, and then pre-tighten all screws.




Figure 18. Door Pre-Tighten from Inside

- **For Occupied Cabinet:** Place the RDHx against the cabinet and slowly open the cabinet door. For people are required to assist - two to hold the door frame, one to open the RDHx, and one to secure the RDHx frame to the cabinet.




Figure 19. Door open

- **For Occupied Cabinet:** Stand outside of the cabinet, insert the Scorpio Bracket into the slot on the RDHx, slide it to align with the L bracket, and then pre-tighten all screws.






Figure 20. Door Pre-Tighten from Outside

- Use a spirit level to check and adjust the RDHx leveling feet.




**Figure 21. RDHx Leveling**

- Tighten all the fixing screws (Torque: 10 N·m).



**Figure 22. Tighten**

- Align and bay the RDHx from top.



**Figure 23. Baying**

- Place the bracket and secure it with M4×8 (Torque: 2.0 N·m).

**NOTE:** To ensure proper sealing, an additional bracket must be used when installing a 48U RDHx in a 52U AI Ready Rack or a taller cabinet from another brand.




Figure 24. Additional Bracket Installation

# Liquid Circuit Connections

## Bottom Feed Instruction

### Tool & Material List




Figure 25. Tool List

### **WARNING**

#### **TIP HAZARD**

- For safety, make sure RDHx and the cabinet are securely fastened and the cabinet bolted to floor or baying together to prevent tipping over.

*Failure to follow these instructions can result in serious injury, death, or equipment damage.*

- Open the RDHx.




Figure 26. Door Open

- **Normal Operation ( $\leq 90^\circ$ ):**

- For routine tasks such as cable installation or daily operations, the door can be opened to  $90^\circ$ .
- Always secure the door using the bottom support bracket to ensure stability before performing any work.
- For the pipe kits connection, the door should be open at  $90^\circ$  degree and fixed by the bottom support bracket as well.

- **Maximum Opening ( $\leq 130^\circ$ ):**

- The door may be opened to  $130^\circ$  only when performing maintenance and need a wider space, and only if the adjacent door is also opened.
- Do not force or pull the door at its maximum opening angle.

- **Safety Precautions:**

- Never open the door beyond the specified limits.
- Always verify that the door is stable and secure before reaching inside or performing any operation.






Figure 27. Door Opening  $90^\circ$  Angle




**Figure 28. Door Opening 90° Angle**



**Figure 29. Door Opening 130° Angle**  
(The adjacent door must also be opened to prevent collisions)

➤ Remove the screws and take the hose cover away.



**Figure 30. Hose Cover Removal**

- Remove the screws and take the Liquid Circuit Protection Module away.

Note: Pull it out first, otherwise the water tray will get stuck.




Figure 31. Liquid Circuit Protection Module Operation

- Remove 2 knurled caps, verify the gas well sealed and release the gas properly.





Figure 32. Verify the gas well sealed then release the gas

## ⚠ WARNING

- For safety, do not remove the hexagonal cap directly. The Pipes can be installed only after the gas has been fully released.


***Failure to follow these instructions can result in serious injury, death, or equipment damage.***

- Remove the hexagonal cap with 2 adjustable spanners to avoid twisting coil copper elbow.



**Figure 33. Hexagonal Cap Removal**

- Remove the cover plate in the interface frame.



**Figure 34. Cover Plate Removal**

➤ Connect the silicone hose end with elbow to coil, pass another end through interface frame cutting and the floor cutting. If there are any gaps between interface frame cutting edge and hose, warp the hose with the 3M sealing strips and seal the gap.

Note:


- First install the blue silicone hose, with reference to the blue label on the coil elbow.
- Ensure the hose elbow is as vertical as possible.
- The installation torque requirement is between 65-75 N·m.

### NOTICE

- Smear a pea sized amount of sealant on the coned face of the coil tail.


***Failure to follow these instructions can result in water leakage, or equipment damage.***






**Figure 35. Hose Connection**

- Connect the other end of the silicone hose to the primary side water circuit with sealant.




**Figure 36. Hose Connection (Facility Side)**

- According to the disassembly steps, install Liquid Circuit Protection Module and hose cover to the RDHx. Tighten the screws and then close the Rear Door Heat Exchanger.



**Figure 37. Liquid Circuit Protection Module Installation**




**Figure 38. Hose Cover Installation**

## Top Feed Instruction

### Tool & Material List



Figure 39. Tool List



- Open the RDHx, Refer the details to page 33 &34





Figure 40. Door Open

➤ Remove those screws and detach Liquid Circuit Protection Module away.

Note: Pull it out first, otherwise the water tray will get stuck.



**Figure 41. Liquid Circuit Protection Module Removal**

➤ Disassemble the Liquid Circuit Protection Module.




Figure 42. Liquid Circuit Protection Module Exploded


➤ Remove 2 knurled caps, verify the gas well sealed and release the gas properly, refer to figure 32.

**⚠ WARNING**

- For safety, do not remove the hexagonal cap directly. The Pipes can be installed only after the gas has been fully released.

*Failure to follow these instructions can result in serious injury, death, or equipment damage.*

- Remove the hexagonal cap with 2 adjustable spanners to avoid twisting coil copper elbow.




**Figure 43. Coil End Cap Removal**

- Connect the silicone hose end with elbow to coil tail.


Note:

- First install the blue silicone tube, with reference to the blue label on the coil elbow.
- Ensure the hose elbow is as vertical as possible.
- The installation torque requirement is between 65-75 N·m.




**Figure 44. Hose Connection**

- Assemble the Liquid Circuit protection module as shown below. If there are any gaps, seal them with 3M sealing strips.



**Figure 45. Hose Sealing**



- Connect the other end of the silicone hose to the primary side water circuit with sealant.



**Figure 46. Hose Connection (Facility Side)**

- Close the RDHx.

## Valve Installation



t -10..120 °C		p <sub>s</sub> 1600 kPa		DN	Rp	mm	80 °C		100 °C		120 °C						100 °C		120 °C									
							KR..	TR..	LR..A		NR..A		SR..A		TRF..		LRF..		NRF..A		SRF..A							
mm	"	L	H	M	L1	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y	X	Y					
R2015-P..-S1	R3015-P..-S1	R2015-1..-S1	R3015-1..-S1	15	1/2"	67	35	36	13	141	75	176	75	186	75	221	80	221	80	181	80	191	90	211	90			
R2015-2P5-S1	R3015-2P5-S1	R2015-4-S1	R3015-4-S1	R2015-6P3-S1	R3015-6P3-S1	15	1/2"	67	44	36	13	150	75	185	75	195	75	230	80	230	80	190	80	200	90	220	90	
R2020..-S2	R3020..-S2	20	3/4"	78	46	41.5	14							200	75	235	80	235	80			205	90	225	90	225	90	
R2025..-S2	R3025..-S2	25	1"	87	46	45	16							200	75	235	80	235	80			205	90	225	90	225	90	
R2032..-S3	R3032..-S3	32	1 1/4"	105	50.5	55.5	19							240	80	240	80					230	90	230	90			
R2040..-S3	R3040..-S3	40	1 1/2"	111	50.5	56	19							240	80	240	80					230	90	230	90			
R3040-25-S4	R3050..-S4	40	1 1/2"	122	62	66.5	19							250	80								240	90				
R2050..-S4	R3050..-S4	50	2"	125	56	68	22							245	80								235	90				
R3050-40-S4	R3050-58-S4	R3050-40-S4	R3050-58-S4	50	2"	142	68	79	22					262	80								252	90				





Figure 47. Valve Installation

## Actuator Installation





Figure 48. Actuator Installation

## Electrical Connections



### Power Panel Overview

➤ Open the front fan cover to find the RDHx Power Panel above the fans.




Figure 49. Fan Cover Open Overview




Figure 50. Power Panel Overview

## Port Definition




Figure 51. Port Definition

Table 9. Port Definition Table

NO.	Port	Function Description
1	Power-A	Power supply input A
2	Power-B	Power supply input B
3	Fans	Power supply for fans
4	FU 1	use for power A
5	FU 2	
6	FU 3	
7	FU 4	Fuse for power B
8	FU 5	
9	FU 6	Fuse for fans
10	FU 7	Fuse for actuator (DC24V)
11	Network port	Network communication
12	USB Type A	Firmware upgrade via USB memory drive
J1	Pin 1_V-	DC24V output for HMI and water leakage device
	Pin 2_V+	
	Pin 3_DI	Water leakage signal digital input
	Pin 4_GR	
	Pin 5_RD	Multi-color LED indicator
	Pin 6_COM	
	Pin 7_D1+	
	Pin 8_D1-	RS485_1 communication for HMI
	Pin 9_G1	
	Pin 10_D2+	RS485_2 communication for fans and actuator
	Pin 11_D2-	

J2	Pin 12_G2	
	Pin 1	N/A
	Pin 2	N/A
	Pin 3	N/A
	Pin 4	N/A
	Pin 5_AI6	Room temp sensor 6
	Pin 6_COM	
	Pin 7_AI1	Air input temp sensor 1
	Pin 8_AI2	Air input temp sensor 2
	Pin 9_AI3	Air input temp sensor 3
	Pin 10_AI4	Air input temp sensor 4
	Pin 11_AI5	Air out temp sensor 5
J3	Pin12_COM	Temp sensors COM ports 1 to 5
	Pin 1_Temp.	Water flow sensor
	Pin 2_Flow	
	Pin 3_GND	
	Pin 4_5V	
	Pin 5_Temp.	Water pressure sensor
	Pin6_Press	
	Pin 7_GND	
	Pin 8_5V	
	Pin 9	N/A
	Pin 10	Alarm out dry contact: common
	Pin 11	Alarm out dry contact: Normally closed
	Pin 12	Alarm out dry contact: Normally open
J4	Pin 1_V-	DC24V output for actuator
	Pin 2_V+	

## Fuse Rating


<b>⚠️ ⚠️ WARNING</b>	
<b>SHOCK HAZARD</b>	
<ul style="list-style-type: none"> <li>• CAUTION: Double pole, neutral fusing. Disconnect mains before servicing. (ATTENTION. Double pôle/fusible sur le neutre. Débrancher l'alimentation avant l'entretien.)</li> <li>• Any parts replaced during maintenance must be the same specification as those being replaced.</li> <li>• Replaced any parts should only be replaced by qualified personnel or contact INOVA.</li> </ul>	
<i>Failure to follow these instructions can result in serious injury, death, or equipment damage.</i>	

Table 10. Fuse Rating Table

Fuse Number	Fuse type	Fuse Rating	Function Description
FU 1	Fast fuse, Ø6.3x32mm	12A/250V	Fuse for power A
FU 2	Fast fuse, Ø6.3x32mm	12A/250V	
FU 3	Fast fuse, Ø6.3x32mm	12A/250V	Fuse for power B
FU 4	Fast fuse, Ø6.3x32mm	12A/250V	
FU 5	Fast fuse, Ø6.3x32mm	10A/250V	Fuse for fans
FU 6	Fast fuse, Ø6.3x32mm	10A/250V	
FU 7	Fast fuse, Ø6.3x32mm	1A/250V	Fuse for actuator (DC 24V)

## Input Power Cord Connection

The IEC 320 C19/C20 power cord is pre-connected with the unit in factory .




IEC 320 C20  
Male Plug

Figure 52. Power Cord Overview

IEC 320 C19  
Female Socket

The Nova Cool RDHx has dual power input ports, allowing for the use of two independent power sources: Power-A and Power-B. If one of the power sources fails, the device will automatically switch to the other power source. Power-A is the preferred source, and the system will only switch to Power-B if Power-A is unavailable. If Power-A is restored, the system will automatically revert to Power-A.

- Connect the C20 end of the Power-A and Power-B power cords to the power supply.



**Figure 53. Connect power cords to the power supply**

## Network cable Connection

- The port shown in the picture is network for client to monitor the RDHx devices.
- Refer to page 137 in case you need to disconnect the network cable.




Figure 54. Network Cable Connection

## Commissioning Tool Connection (Option)

When configuring the parameters, use the provided wire harness to connect the RDHx communication port to the commissioning tool.


Before use, insert the disk into the HMI USB port.



**Figure 55. Commissioning Tool Connection**

## Actuator Cable Connection

Plug the female connector of the A17 harness into the actuator's male connector and secure the nut.



**Figure 56. Actuator Cable Connection**

## Leak Detection Rope Wiring

- Connect the rope (orange part) to the leak detection cable terminal (grey cable end).



Figure 57. Leak Detection Rope Connection

- Wrap the leakage detection cable in a spiral pattern around the pipes, securing it with tie wraps every 200mm.




Figure 58. Leakage Rope Routing

## Room Temperature Sensor Installation

The room temperature sensor monitors the server's air intake temperature to support accurate thermal management.

- Cut the cable tie, release the room temperature sensor on the RDHx.
- Route the cable towards the front of the cabinet.




Figure 59. Room Temperature Sensor Cable Routing

- Secure the room temperature sensor to the front door using cable ties.

**CAUTION:** Do not let the temperature sensor touch metal directly. Insert it into the provided holder and secure the holder to the front door (The sensor position can be adjusted according to the actual situation on site)




Figure 60. Room Temperature Sensor Mounted

## Capacity Sensor Installation

### Flow and Temp Sensor VFS Installation



**Figure 61. Installation Diagram**

\*Suggest installing the VFS on the entering water (supply) side.

### Power Cable Connection



**Figure 62. Material List**

- Connect the sensor wire harness to the VFS sensor.



**Figure 63. Pre-connection**

- Connect the A20 harness to the control box J3 terminal ports.
- Connect the female connector of the A20 harness to the male connector of the VFS wire and secure them.





Figure 64. A20 Harness Connection

Table 11. J3 Terminal Ports

Terminal	Wire Number	Description
J3	Pin 1	T
	Pin 2	F
	Pin 3	GND
	Pin 4	5V

## Pressure and Temp Sensor RPS Installation



**Figure 65. Installation Diagram**

\*Suggest installing the RPS on the leaving water (return) side.

## Power Cable Connection




**Figure 66. Material List**

- Insert the Sensor Wire Harness to the RPS sensor.



**Figure 67. Pre-connection**

- Connect the A21 harness to the corresponding ports on the control box J3 terminal.
- Connect the female connector of the A21 harness to the male connector of the RPS harness, then secure them.



**Table 12. J3 Terminal Ports**

**Figure 68. A21 Harness Connection**

Terminal	Wire Number	Description
J3	Pin 5	T
	Pin 6	P
	Pin 7	GND
	Pin 8	5V

# Part V. System Setup and Start-up

## Pre-Activation Checklist

### Physical Inspection

- Ensure the unit is securely mounted and aligned with the designated rack.
- Confirm that all mechanical fasteners and support structures are properly tightened.
- Verify that the cooling unit is free of any physical damage or obstructions.

### Liquid Circuit Checks

- Inspect all flexible hoses and fittings for secure connections and potential leaks.
- Ensure the water inlet and outlet connections comply with specified pressure and temperature requirements.
- Confirm that the isolation valves and pressure-independent control valves (if applicable) are correctly positioned.
- Verify the presence of a properly functioning leakage detection sensor.

### Electrical and Control System Verification

- Ensure both A & B power feeds are correctly connected and securely fastened.
- Confirm that the Automatic Transfer Switch (ATS) is operational (if applicable).
- Verify the integrity of all power and signal cables.
- Check that all network communication lines are correctly wired and terminated.
- Ensure that the control panel and monitoring system are properly mounted and responsive.

## Power-On Procedures

### Power Supply Activation

- Turn on both A & B power sources to supply power to the NovaCool RDHx.
- Verify that the LED status indicators on the control panel illuminate correctly.

### System Initialization

- The unit will conduct a self-diagnostic check to ensure all components are functioning correctly.
- The controller will verify the status of fans and temperature sensors.

### Liquid Circuit Activation

- Open the necessary isolation valves to allow coolant flow through the system.
- Gradually pressurize the system to prevent water hammer effects.
- Ensure that the water temperature and flow rate sensors register stable values.

### Fan and Valve Operation Check

- Initiate a test run of the EC fans and verify that all units are operational.
- If applicable, check that the motorized control valves respond correctly to system commands.
- Confirm System Readiness
- Closely monitor the system for any error messages or warning codes before proceeding.
- Validate that all real-time monitoring parameters (temperature, pressure, flow rate) are within acceptable limits.

## Initial Setup

### Control Panel Configuration

- Access the control panel and navigate to the main menu.
- Verify and adjust the following operational parameters as needed:
  - Target supply air temperature
  - Fan speed settings (Auto/Manual mode)
  - Water flow rate thresholds
  - Leak detection sensitivity
- Network and Communication Setup
- Configure the MODBUS settings for remote monitoring.
- Assign a unique IP address if integrated with a Data Center Infrastructure Management (DCIM) system.
- System Performance Validation
- Conduct a final operational test by running the unit under a simulated load condition.
- Confirm that the cooling capacity meets expected performance levels.
- Record baseline operating data for future maintenance and troubleshooting reference.

# Part VI. Commission Tool Configuration

## Hardware Display



HMI stands for Human-Machine Interface and refers to a dashboard that enables a user to communicate with a machine, computer program or system. Technically, the term HMI can be applied to any screen that someone uses to interact with a device, but it's typically used to describe such screens used in industrial settings. HMIs display real-time data and allow a user to control machinery using a graphical user interface.

The HMI used in this **NovaCool RDHx** is the which features 4.3 wide TFT touchscreen display and packed with an Enclosure.

## Parts Identification





Figure 69. Parts Diagram

Table 13. Parts Identification

A	Power Contactor
B	USB (Type-A) Interface
C	USB (Mini-B) Interface
D	RTC Battery Cover
E	Ethernet Interface
F	Serial Interface

## System Status

When the HMI is powered On RDHx System Status is generally displayed.




**Figure 70. System Status**

- The “Air In Temp” displays the temperature of air entering the coil. This value controls the fan speed.
- The “Air Out Temp” shows the Air off temperature which is controls the Valve Open/Close
- The “Rack in Temp” displays the rack’s front temperature and is used for monitoring only—it does not control any system functions.
- The “EWT” shows the entering water temperature. This value is available only if the VFS sensor is installed.
- The “LWT” shows the Leaving Water (Return Water) temperature from the unit, this value will be available only the RPS sensor is available.



-  symbol is Fan Running Speed,  symbol is Valve Open position.
- “dP value” shows the actual differential pressure.




**Figure 71. dP value**



- F1 to F6 shows the individual Fan running speed.  symbol is Valve Open Command.
- The “Water flow” shows the Water flow to the unit, this value will be available only the VFS EPIV/EV sensor is available.

- The “Water pressure shows the Water pressure (Supply/Return Water) from the unit, this value will be available only the RPS EPIV/EV sensor is available.
- Capacity shows unit running capacity
- Valve command Shows the valve opening command percentage from the controller.

## Power Status




**Figure 72. Power Status**

There are Two Power sources are available in the system POWER A and POWER B.

- IF the Power is available, display shows as Normal.
- IF the Power is not available, display shows as Failure.

## Selection Menu



**Figure 73. Selection Menu**



: This Symbol navigates to Network setting, for Web UI or Any other Integration.

## Control – Metric Selection




Figure 74. Metric Selection

## Temperature Settings




Figure 75. Temperature Settings



**Operational Settings** : This Icon take into the Operational settings screen, password protected.

- The Room & Air in Temperature parameters are used to control the fan speed.
- The difference between Room temperature and Air in Temperature setpoint range over which fan will go from minimum speed and maximum speed.
- The Air Out Temperature parameters are used to control the Valve open/close.
- The differential values are used to calculate the minimum and maximum temperature values that unit has to be operated.

## Control – Fan




Figure 76. Control Fans (C6~C9)

- The fans are controlled by the temperature on the front of RDHx and back side of IT Equipment.
- The fan parameters can be varied depending on equipment and operation parameters.
- The Fan Minimum speed(C6) is the speed a fan operates at when Air in temperature below the Room temperature setpoint.
- In startup all the fans operate at Initial speed(C8).
- The Fan Maximum speed(C7) will have been set at site based on expected maximum speed that unit transfers the heat from the RDHx.
- Fan Differential Delay(C9) is ensuring the fan speed modulation on periodically to avoid the false




Figure 77. Control – Fans (C14~C19)

results.

- No of Fans (C14...C19) can be enabled based on-Site requirements, by default all the fans are active.
- If Fan is not activated, alarms of the corresponding fan also do not activate.

## Control – Valve



Figure 78. Control – Valve

- The valve is controlled by the Air Out temperature
- The Valve Minimum Open(C10) is the position when Air Out temperature is below the setpoint.
- In startup all the valve opens at Initial Open position(C12), this can adjust at site conditions.
- The Valve Maximum open(C11) will have been set at site based on the expected maximum speed that unit transfers the heat from the RDHx.
- Valve differential delay(C13) is ensuring the valve opening periodically to avoid the false results.
- The Bus fail action (C13.a) decides the required action when the valve/fan lost the communication with the controller

## Water Sensor Settings




Figure 79. VFS - RPS

- VFS is a sensor used to monitor the Water Temperature and Flow rate.
- RPS is a sensor used to monitor the Water) Temperature and Pressure.
- If these C20, C21 are not On, the functions of the sensor are not activated.
- C22 is a parameter to enable the EPIV valve, for EPIV C21 also required to measure pressure.
- C23 is a parameter to enable the EV valve, if it enables remaining option will reset to default.
- C24 & C25 is parameters are used to calculate the actual flow and temperature according to the valve models used (applicable for EPIV &EV).

## Control- dP sensor




Figure 80. Control-DP sensor

- C26 Parameter to activate dP sensor function.
- C27 Parameter to set point value to control the fans
- C28 dP Deadband: it's a hysteresis value to adjust (+/-) from the Set point
- C29 Parameter to increase the fan speed by %
- C30 Parameter is a Delay to read the actual dP
- C31 dP Range Min/ Max is decide based on the actual reading from the unit.

## Alarm Settings





Figure 81. Alarm Settings (A1~A6)

- A19 Setup an Alarm to indicate the actual dP pressure time to reach the set dP .
- A20 & A21 Setup an Alarm to indicate the dP value that reaches preset pressure.
- A22 & A23 Setup an Alarm to indicate the dP sensor value that reaches preset range.
- A24 & A25 is a delay for valve & Fan communication lost with controller, if it does not resume the communication with in delay period, then the respective action(C13.a) will take over.

## Factory Settings




**Figure 82. Factory Settings**



This Icon takes into the factory settings Screen (Maintenance purpose, Password protected).

- F1 & F2 are the parameters of fan, it can be modified at site operations, so that modulation will happen with in this set values.
- F3 & F4 are the parameters of valve, it can be modified at site operations, so that valve position modulation will happen with in this set values.
- F5 & F6 are the Offset parameters to decide the ratio of fan speed and valve opening modulations.

## Leakage Sensor Settings



**Figure 83. Leakage Sensor Settings**

- F7 parameter used to activate the leakage sensor function normally is an optional sensor.
- F8 is delay and F9 is count that decides if the leakage happens during the operation and creates an alarm as leakage fault.
- If leak detects first time in the unit it shows Water leakage fault,
- The second time the leak detects it shows Water leakage fault (Critical),
- And the Third time the leak detects it shows as Water leakage fault (Very Critical),
- If F11 parameter is enabled and the leakage fault happens more than the notify cycle value(F9), then the alarm will show as Water Leakage Fault (Need Action) and all the fans will be running at

maximum speed, and the valve will close completely. once the leak detect sensor becomes normal then need to press the Alarm Ack button to reset it.

- F10 is an Option to change fan modulation (Optional).
- F12 parameter is to confirm the valve installed position (Supply/Return)

## Fan Replace

Method: 1

### Fan Replace

PM4	Fan Address	12
PM5	Fan Address Confirm	No

If it is a new fan (Default address is 247) follow the below Steps

1. Place the fan into the unit
2. Enter the required fan address (PM4)
3. Press the Fan address confirm button (PM5) once the fan address updates the confirmation button will become initial position (No)
4. Disconnect the fan from the power for 30 seconds, LED on the fan will become off then connect the fan to the power

Method :2

### Restore fan to factory setup

PM6	Reset Fan Address to default	12
PM7	Fan Address Reset	No

If the fan is old one and it's having the existing address of (2...7) any, follow below steps

1. Place the fan into the unit.
2. Enter the fan address (PM6) that needs to be restore default settings.
3. Press the Fan address confirms button (PM7) once the fan address updates the confirmation button will become initial position (No)
4. Disconnect the fan from the power for 30 seconds, LED on the fan will become off then connect the fan to the power

Now the fan goes to default settings (Like New fan)

Follow Method 1.

**Note:** If Both fans are having the same Address, then address conflict will happen, (For example consider Resetting fan address is 3 and already in running RDHx unit, one of fan also having address as 3, both fans cannot use same address then both fans will stop and misbehave.

To avoid this, disconnect the running fan from the power and change the restoring fan to required address then reconnect both fans.

## Preventive Maintenance Settings




Figure 84. Preventive Maintenance Settings

- PM1 Parameter enables the preventive maintenance warning notification from the date of selection (Q. Yearly or H. Yearly or Yearly). It's mandatory to select period to enable PM warning of unit.
- Q. Yearly: Every 3 Months from the date of selection warning  icon will be displayed.
- H. Yearly: Every 6 Months from the date of selection warning  icon will be displayed.
- Yearly: Every 12 Months from the date of selection warning  icon will be displayed.
- PM2 is reset the current period of PM setting, if necessary, only for Maintenance purpose of unit.
- After the PM activity, need to again enable the PM1parameter for next cycle.
- PM3 is an option to enter the Installation date for calculate the number of days from the installation date.

## IO - Status Analog




Figure 85. IO Status Analog

## IO - Status Digital

- The IO status of Analog & Digital is used to monitor the healthy and working conditions of hardware devices which are used in RDHx.




Figure 86. IO Status Digital

## Program Settings




Figure 87. Program Settings



Program  
Settings

This Icon takes into program settings, password protected.

## Alarm Bypass Screen




Figure 88. Alarm Bypass Screen

Basically, program settings are applicable for Manufacturers, Password protected.

## Air In Sensor bypass Settings




Figure 89. Sensor Bypass Settings

- I17 to I20 is option to enable/Disable the Air In sensor( Only 1 case of failure)  
Also should not bypass more than one sensor.
- I21 shows the available Air in sensor in online.

## Sensor Calibration




Figure 90. Sensor Calibration

It's used to calibrate the Sensor reading (Temperature sensor only), the calibration should do it on only in Celsius mode (metric selection).

- Sensor select: Select the sensor that needs to calibrate from 1 to 7
- Sensor read value: Actual sensor reading shows here
- Required value: The value that needs to overwrite
- Offset value: The difference between the actual sensor reading and required value.
- Gain: Calculation factor by default it should 1
- Corrected value: The calibrated value shows here.
- Confirm: After confirming the calibrated value press confirm button to apply the calibrated values into the unit.
- After the calibration the status can be seen in Sensor status page.






Figure 91. Sensor Status



Sensor Status	Sensor Reading		Corrected Value	1234 / 12 /12 12:12:12
	123	123		
Air In Temp-1	123	123		
Air In Temp-2	123	123		
Air In Temp-3	123	123		
Air In Temp-4	123	123		
Air Out Temp	123	123		
Room Temp	123	123		
dP Sensor	1234	1234		

Figure 92. Sensor Status

## Network Settings



Network Setting	1234 / 12 /12 12:12:12
Automatic DCHP	<input checked="" type="radio"/> Disable
Ip Address	123 123 123 123
Subnet Mask	123 123 123 123
Default Gateway	123 123 123 123
DNS Server	123 123 123 123

Figure 93. Network Setting

- The RDHx is delivered with default Ip Address of 10.0.0.100 and sub net is 255.255.255.0.
- Ip address and other network details can be edited as per the site network requirement.
- The other method of assigning Ip details is enable the Automatic DCHP method, once the DCHP option is enabled automatically Ip details will assign as per the network connection so the same can be used for other integrations.

## Date/Time Settings




Figure 94. Data And Time



Date/Time This Icon takes into Date/Time Adjust screen.

- The RDHx controller has internal date/time memorizing capabilities, but sometimes it necessary to adjust Date/ Time based on region/Zone changes.
- Enter the present Date/Time if it necessary and press the Controller Apply button in the above screen so that actual Date/Time will update to controller, the same timing will follow.
- If the HMI display shows the incorrect Date/Time, then press the Display apply button to adjust the actual Date/Time to Display.

## Manual Testing




Figure 95. Manual Test

Note:

Manual Mode operates only when the unit is “OFF” condition. After testing completes its mandatory to select “Auto” so that system will function in “Auto Mode”

- Select the Manual Mode to test the RDHx in Manual Mode.
- Manual fan test possible here, Set the required speed (10 % to 100%) the fan will start running in manual mode.
- Select the button to “OFF” to stop the fan in manual mode.
- Select the button to “ON” and enter “0” to stop the fan in manual mode. So that fan will not be running.

- Manual Valve test possible here, Set the required opening command (10 % to 100%) the valve will start opening in manual mode.
- Select the Valve stop to “OFF” to stop the valve in manual mode.
- Select the valve stop to “ON” and enter “0” in valve command. So that valve will be fully closed.

## Alarms

## Active Alarm - View


**Figure 96. Alarm View**



This Icon takes into alarm view screen,

- Here we can see all the recent alarms
- If any severe alarm appears it needs to be acknowledged (Press Alarm Ack Button), then it will reset otherwise the alarm state will be in set condition.
- The active alarms display in red background, and acknowledged alarms displayed in white background.

## Active History



Alarm History			
Date	Time	AlarmMessage	AlarmStatus


Figure 97. Alarm History



Alarm Log This Icon takes into Alarm History screen

- Here we can find the recent logged alarms.
- This will help for maintenance or service engineers to identify the faults and analyze the root cause.

## System Information



System Info	
Device Name	: NovaCool RDHx
Model No	: Gen 1
PLC Version	: ABCDEFG
HMI Version	: XAI-1.0
Mac Address	: 123 : 123 : 123 : 123 : 123 : 123
Manufacturer	: Inova DC
Contact	: <a href="mailto:sales@inovadc.com">sales@inovadc.com</a>

Figure 98. System Information



System Info This Icon takes into system information screen.

- THE RDHx unit details has been attached to the above screen, in case of any support client can contact through the above mail is [sales@inovadc.com](mailto:sales@inovadc.com).

## Modbus Register List

Parameter Code	Data Type	Address	Name	Available set values	Factory Set Values	Units	Access
	Bool	16404	Unit On/Off	ON/OFF	OFF		R/W
<b>Manual Test</b>							
	Bool	9049	Fan1_TurnOff	ON/OFF	ON		R/W
	Bool	9050	Fan2_TurnOff	ON/OFF	ON		R/W
	Bool	9051	Fan3_TurnOff	ON/OFF	ON		R/W
	Bool	9052	Fan4_TurnOff	ON/OFF	ON		R/W
	Bool	9053	Fan5_TurnOff	ON/OFF	ON		R/W
	Bool	9054	Fan6_TurnOff	ON/OFF	ON		R/W
	Bool	9075	Mode Selection	Manual/Auto	Auto		R/W
	Int	9076	Fan1Speed	0	0	%	R/W
	Int	9077	Fan2Speed	0	0	%	R/W
	Int	9078	Fan3Speed	0	0	%	R/W
	Int	9079	Fan4Speed	0	0	%	R/W
	Int	9080	Fan5Speed	0	0	%	R/W
	Int	9081	Fan6Speed	0	0	%	R/W
	Int	9082	ValveCommand	40	40	%	R/W
	Bool	9086	Stop	ON/OFF	ON		R/W
<b>Factory Settings</b>							
F1	Int	16407	Fan Minimum Rpm	0	0		R/W
F2	Int	16408	Fan_MaxRpm	2600	2600		R/W
F3	Int	16409	Valve Minimum Open	0	0		R/W
F4	Int	16410	Valve Maximum Open	10000	10000		R/W
F5	Int	16411	Fan Offset Value	20	20		R/W
F6	Int	16412	Valve Offset Value	20	20		R/W
F7	Bool	16413	Water Leakage Sensor	ON/OFF	ON		R/W
F8	Int	16414	Leakage fault Delay	25	25	Sec	R/W
F9	Int	16415	Leakage notification cycle	3	3		R/W
F10	Bool	16468	Fan Ramp Modulation Change	ON/OFF	OFF		R/W
F11	Bool	16480	Leakage Action Modulation	ON/OFF	OFF		R/W
F12	Bool	16496	Valve placement Line	Return/Supply	Supply		R/W
<b>Preventive Maintenance</b>							
PM1			PM Notification Cycle				R/W
	Int	16425	Q.Yearly	ON/OFF	OFF		R/W
	Int	16426	H.Yearly	ON/OFF	OFF		R/W
	Int	16427	Yearly	ON/OFF	OFF		R/W
PM2	Bool	9133	PM Reset	ON/OFF	OFF		R/W
PM3			Installation Date				R/W
	Int	16457	YYYY		2026		R/W
	Int	16458	MM		1		R/W
	Int	16459	DD		1		R/W

Fan Replace							
PM4	Int	9083	Fan Node Address	0	0		R/W
PM5	Bool	9085	Fan Address Confirm	NO/Confirm	NO		R/W
PM6	Int	9153	Reset Fan address to default	0	0		R/W
PM7	Bool	9155	Fan Address Reset	NO/Confirm	NO		R/W
IO Status (No settings required these are actual values)							
I1	Int	9097	AI1.Air In NTC-1	0	0		R
I2	Int	9098	AI2.Air In NTC-2	0	0		R
I3	Int	9099	AI3.Air In NTC-3	0	0		R
I4	Int	9100	AI4.Air In NTC-4	0	0		R
I5	Int	9101	AI5.Air Out NTC-5	0	0		R
I6	Int	9102	AI6.Room Temperature	0	0		R
I7	Int	9103	AI7.Humidity (Optional)	0	0		R
I8	Int	9104	AI8.dP Sensor	0	0		R
I8	Int	9105	AI9.Water Supply Temp	0	0		R
I9	Int	9106	AI10.Water Supply Flow	0	0		R
I10	Int	9107	AI11.ReturnWaterTemp	0	0		R
I11	Int	9108	AI12.ReturnWaterPress.	0	0		R
I12	Bool	9109	DI3-Water Leakage sensor	ON/OFF	OFF		R
I13	Bool	9110	DI4-Power Source A	ON/OFF	ON		R
I14	Bool	9111	DI5-Power Source B	ON/OFF	ON		R
I15	Bool	9112	DO3-RedLight	ON/OFF	OFF		R
I16	Bool	9113	DO4-GreenLight	ON/OFF	OFF		R
Air In Sensor Bypass							
I17	Bool	16781	Air In Temp Sensor -1	Enable/Disable	Disable		R/W
I18	Bool	16782	Air In Temp Sensor -2	Enable/Disable	Disable		R/W
I19	Bool	16783	Air In Temp Sensor -3	Enable/Disable	Disable		R/W
I20	Bool	16784	Air In Temp Sensor -4	Enable/Disable	Disable		R/W
I21	DInt	9160	AirIn Sensor Online		Actual		R/W
	Bool	9172	Do Not Bypass Further Sensor		Invisible		R
Sensor Calibration							
			Sensor Select	0.None 1.Air In Temp Sensor -1 2.Air In Temp Sensor -2 3.Air In Temp Sensor -3 4.Air In Temp Sensor -4 5.Air Out Sensor 6. Room Temp Sensor 7.dp sensor	0		R/W
	Int	9192					
	Real	9190	Sensor Read Value		Actual	°F	R
	Real	9194	Required Value		0.0	°F	R/W
	Real	9186	Offset Value		0.0	°F	R
	Real	9184	Corrected Value		0.0	°F	R
	Real	16511	Gain		1.0	°F	R/W
	Bool	9193	Confirm	ON/OFF	OFF	°F	R/W

Sensor Status							
	Real	9196	Air In Temp-1		Actual	°F	R
	Real	9198	Air In Temp-2		Actual	°F	R
	Real	9200	Air In Temp-3		Actual	°F	R
	Real	9202	Air In Temp-4		Actual	°F	R
	Real	9204	Air Out Temp		Actual	°F	R
	Real	9206	Room Temp		Actual	°F	R
	Real	9218	dP sensor		Actual	Wc	R
	Real	8994	Air In Temp-1 - Corrected Value		Actual	°F	R
	Real	8996	Air In Temp-2 - Corrected Value		Actual	°F	R
	Real	8998	Air In Temp-3 - Corrected Value		Actual	°F	R
	Real	9000	Air In Temp-4 - Corrected Value		Actual	°F	R
	Real	9002	Air Out Temp - Corrected Value		Actual	°F	R
	Real	9004	Room Temp - Corrected Value		Actual	°F	R
	Real	9227	dp Actual value - Corrected Value		Actual	Wc	R
Metric Selection							
	Bool	16428	Celsius/Fahrenheit	C/F	F		R/W
	Bool	16447	Bar/Psi	Bar/Psi	Psi		R/W
	Bool	16448	Lpm/Gpm	Lpm/Gpm	Gpm		R/W
	Bool	16529	Pa/Wc	Pa/Wc	Wc		R/W
Control- Temperature							
C1	Real	16384	Room Temperature Setpoint	24	80	°F	R/W
C2	Real	16388	Air In Temperature Setpoint -Max	45	115	°F	R/W
C3	Real	16390	Air In Temperature Differential	1	1	K	R/W
C4	Real	16392	Air Out Temperature Setpoint	23	79	°F	R/W
C5	Real	16398	Air Out Temperature Differential	1	1	K	R/W
Control- Fans							
C6	Int	16400	Fan Minimum Speed	30	20	%	R/W
C7	Int	16445	Fan Maximum Speed	100	100	%	R/W
C8	Int	16405	Fan Initial Speed	30	20	%	R/W
C9	Int	16402	Fan Differential Delay	30	30	Sec	R/W
Control- Valve							
C10	Real	16396	Valve Minimum Open	15	5	%	R/W
C11	Real	16394	Valve Maximum Open	70	100	%	R/W
C12	Int	16446	Valve Initial Open	30	20	%	R/W
C13	Int	16401	Valve Differential Delay	180	180	Sec	R/W
C13.a	Int	16552	Bus Fail Action	1 & 2	1		R/W
Control- Fans							
C14	Bool	16472	Fan 1 Active	ON/OFF	ON		R/W
C15	Bool	16473	Fan 2 Active	ON/OFF	ON		R/W
C16	Bool	16474	Fan 3 Active	ON/OFF	ON		R/W
C17	Bool	16475	Fan 4 Active	ON/OFF	ON		R/W
C18	Bool	16476	Fan 5 Active	ON/OFF	ON		R/W
C19	Bool	16477	Fan 6 Active	ON/OFF	ON		R/W
VFS-RPS							
C20	Bool	16478	VFS Active	ON/OFF	OFF		R/W
C21	Bool	16479	RPS Active	ON/OFF	ON		R/W
C22	Bool	16488	EPIV Active	ON/OFF	ON		R/W
C23	Bool	16495	EV Active	ON/OFF	OFF		R/W
C24	Real	16489	Vnom	0.4..5.0	1		R/W
C25	Real	16491	Unit factor	0.01	0.01		R/W

Control- Dp Sensor							
C26	Bool	16519	dP sensor Enable	ON/OFF	ON		R/W
C27	Real	16520	dP Set point	10	0.02	Wc	R/W
C28	Real	16522	dP Deadband	2	0.008	Wc	R/W
C29	Real	16524	dP Kpi	0.5	0.5	%	R/W
C30	Dint	16526	dP Ti	10	10	Sec	R/W
C31A	Real	16530	dP Range - Min	-100	-0.4	Wc	R/W
C31B	Real	16532	dP Range - Max	100	0.4	Wc	R/W

Alarm Settings							
A1	Real	16449	Air In Temp -Low	20	68	°F	R/W
A2	Real	16451	Air In Temp High	60	140	°F	R/W
A3	Real	16429	Air Out Temp -Low	17	60	°F	R/W
A4	Real	16431	Air Out Temp -High	27	82	°F	R/W
A5	Real	16433	Water In Temp - Low	15	60	°F	R/W
A6	Real	16435	Water In Temp - High	25	80	°F	R/W
A7	Real	16437	Water Out Temp - Low	15	60	°F	R/W
A8	Real	16439	Water Out Temp - High	40	105	°F	R/W
A9	Int	16441	Fan Speed Threshold	2	2	%	R/W
A10	Int	16442	Fan Speed Threshold Delay	30	30	Sec	R/W
A11	Int	16443	Valve Fbk Threshold	2	2	%	R/W
A12	Int	16445	Valve Fbk Threshold Delay	30	30	Sec	R/W
A13	Real	16386	Rack In Temp Low	17	75	°F	R/W
A14	Real	16453	Rack In Temp High	27	82	°F	R/W
A15	Real	16460	Water In Flow Low	10	1.5	Gpm	R/W
A16	Real	16462	Water In Flow High	140	37	Gpm	R/W
A17	Real	16464	Return Water Press Low	2	29	Psi	R/W
A18	Real	16466	Return Water Press High	6	87	Psi	R/W
A19	DINT	16536	dp Value Alarm Delay	60	60	Sec	R/W
A20	Real	16540	dp Actual Value Low	0	0	Wc	R/W
A21	Real	16542	dp Actual Value High	90	0.36	Wc	R/W
A22	Real	16544	dp Sensor Range Low	-90	-0.36	Wc	R/W
A23	Real	16546	dp Sensor Range High	90	0.36	Wc	R/W
A24	Int	16550	Valve communication delay	60	60	Sec	R/W
A25	Int	16551	Fan communication delay	60	60	Sec	R/W

#### Program Settings(No Access Manufature only)

Status							
	Real	9064	Air In Temp		Actual	°F	R
	Real	9002	Air Out Temp		Actual	°F	R
	Real	9004	Rack In Temp		Actual	°F	R
	Real	9008	EWT(Enter Water Temperature)		Actual	°F	R
	Real	9012	LWT(Leaving Water Temperature)		Actual	°F	R
	Int	9096	Fan Speed Command		Actual	%	R
	Real	8966	Valve Open		Actual	%	R
	Real	9073	Capacity		Actual	Kw	R
	Int	8960	F1 Speed		Actual	%	R
	Int	8961	F2 Speed		Actual	%	R
	Int	8962	F3 Speed		Actual	%	R
	Int	8963	F4 Speed		Actual	%	R
	Int	8964	F5 Speed		Actual	%	R
	Int	8965	F6 Speed		Actual	%	R
	Real	9010	Water Flow		Actual	Gpm	R
	Real	9014	Water Pressure		Actual	Psi	R
	Int	9063	Valve command		Actual	%	R
	Real	9220	dP Value		Actual	Wc	R

Power Status							
	Bool	9066	Power A	Normal/Failure	ON : Normal OFF: Failure		R
	Bool	9067	Power B	Normal/Failure	ON : Normal OFF: Failure		R
Alarm History - All Alarm history shows here							
Date/Time							
Date	Int	8750, 8749, 8748	Enter the present date/Time and press to apply to controller	YYYY:MM:DD	2026:01:01		R/W
Time	Int	8745, 8744		HH:MM:SS	0:00:00		R/W
Display	Bool	8751	HMI device actual time displays here, Press apply to update actual date/time to display	Apply			R/W
Alarms List							
A01	Bool	9048	A01 : Valve Communication Fault				R
A02	Bool	8982	A02: Fan1 Communication Fault				R
A03	Bool	8983	A03: Fan2 Communication Fault				R
A04	Bool	8984	A04 : Fan3 Communication Fault				R
A05	Bool	8985	A05: Fan4 Communication Fault				R
A06	Bool	8986	A06: Fan5 Communication Fault				R
A07	Bool	8987	A07: Fan6 Communication Fault				R
A08	Bool	8972	A08 : Power Source A fault				R
A09	Bool	8973	A09 : Power Source B fault				R
A10	Bool	9095	A10 : Air In Temp Sensor 1 failed				R
A11	Bool	8989	A11 : Air In Temp Sensor 2 failed				R
A12	Bool	8990	A12 : Air In Temp Sensor 3 failed				R
A13	Bool	8991	A13 : Air In Temp Sensor 4 failed				R
A14	Bool	9016	A14 : Room Temperature sensor Failed				R
A15	Bool	8993	A15 : Room Humidity Sensor Failed				R
A16	Bool	8992	A16 : AirOut Temperature Sensor Failed				R
A17	Bool	9018	A17: In Water Flow Sensor Failed				R
A18	Bool	9017	A18: In Water Temperature Sensor Failed				R
A19	Bool	9019	A19 : Return Water Temperature Sensor Failed				R
A20	Bool	9020	A20 : Return Water Pressure Sensor Failed				R
A21	Bool	8969	A21 : AirIn Temperature is High				R
A22	Bool	8970	A22 : AirIn Temperature is Low				R
A23	Bool	9122	A23 : AirOut Temperature is High				R
A24	Bool	8971	A24: AirOut Temperature is Low				R
A25	Bool	9055	A25 : Room Temperature is High				R
A26	Bool	9056	A26 : Room Temperature is Low				R
A27	Bool	9140	A27 : Air In Process Temperature High				R
A28	Bool	9141	A28 : Air In Process Temperature Low				R
A29	Bool	9142	A29 : Air Out Process Temperature High				R
A30	Bool	9143	A30 : Air Out Process Temperature Low				R
A31	Bool	8968	A31: Water Leakage Fault (Need Action)				R
A32	Bool	9119	A32: Fan1 Threshold Value Not in Range				R
A33	Bool	9123	A33: Fan2 Threshold Value Not in Range				R
A34	Bool	9124	A34: Fan3 Threshold Value Not in Range				R
A35	Bool	9125	A35: Fan4 Threshold Value Not in Range				R

A36	Bool	9126	A36: Fan5 Threshold Value Not in Range			R
A37	Bool	9127	A37: Fan6 Threshold Value Not in Range			R
A38	Bool	8974	A38 : Valve Threshold Value Not in Range			R
A39	Bool	9115	A39: In Water Temperature is High			R
A40	Bool	9116	A40: In Water Temperature is Low			R
A41	Bool	9118	A41: Out Water Temperature is High			R
A42	Bool	9117	A42: Out Water Temperature is Low			R
A43	Bool	9137	A43 : Entering Water Flow High			R
A44	Bool	9136	A44 : Entering Water Flow Low			R
A45	Bool	9139	A45: Leaving Water Pressure High			R
A46	Bool	9138	A46: Leaving Water Pressure Low			R
A47	Bool	9150	A47 : Water Leakage Fault			R
A48	Bool	9151	A48 : Water Leakage Fault (Critical)			R
A49	Bool	9152	A49 : Water Leakage Fault (Very Critical)			R
A50	Bool	8975	A50 : Fan1 Node Address :2 conflict			R
A51	Bool	8976	A51 : Fan2 Node Address :3 conflict			R
A52	Bool	8977	A52 : Fan3 Node Address :4 conflict			R
A53	Bool	8978	A53 : Fan4 Node Address :5 conflict			R
A54	Bool	8979	A54 : Fan5 Node Address :6 conflict			R
A55	Bool	8980	A55 : Fan6 Node Address :7 conflict			R
A56	Bool	9222	A56 : Dp Setpoint Not reached			R
A57	Bool	9223	A57 : Dp Actual Value Low			R
A58	Bool	9224	A58 : Dp Actual Value High			R
A59	Bool	9225	A59 : Dp Sensor Value Out of Range (Low)			R
A60	Bool	9226	A60 : Dp Sensor Value Out of Range (High)			R

RS 485 Communication Settings	
HMI Display	
SIO Type	RS 485
Speed	38400
Data Length	8 Bits
Parity Bit	Even
Stop Bits	1 Bit
Flow Control	None
PLC Configuration (RS 485)	
Mode	Modbus Master
Baud Rate	38400
Serial Parity	No Parity
Serial Databit	8 Data bits
Serial Stopbit	2 Stop Bit

# Web User Interface Configuration

## Web Configuration

The supported Web browsers are Google Chrome (mobile and desktop), Mozilla Firefox, Microsoft Edge.

## Web Access

Default controller Ip address; 10.0.0.100

Default controller Subnet: 255.255.255.0

Laptop Network Ip should be in this series 10.0.0.XXX

## Log on Web UI

- Step 1: Connect the Lan cable between Controller and Laptop.
- Step 2: Enter the controller Ip address in network browser (10.0.0.100)




Figure 99. Log on

- Step :3 Enter Username: “administrator”, Default Password: “123456”, then Sign in. The screen below will be displayed.

## Change Password

After successful login, you are required to change the default password. Input the current password and new password twice to confirm. Press “Apply” to complete set up new password.

After successful login below tabs will be displayed.




Figure 100. Login Tabs

## Home

Unit Turned On/Off here. When the unit is turned off, no alarms will be generated, the fans will not run, and the valve will close except for communication alarms.




Figure 101. Unit Control




Figure 102. Unit Control


- The “Air in Temp” shows the Air on into Coil temperature which is controls the Fan speed
- The “Air Out Temp” shows the Air off temperature which is controls the Valve Open/Close
- The “Rack in Temp” shows the Rack front temperature, this has no control function.
- The “Fan speed” shows the fan running speed.
- The “Valve Open” shows position of valve open condition

- The “Capacity” shows the actual running capacity of unit.



**Figure 104. Fan Status**

- Fan feedback shows the F1 to F6 individual Fan running speed.



**Figure 105. Water Status**

- The “EWT” shows the Entering Water temperature to the unit, this value will be available only the VFS sensor is available.
- The “LWT” shows the Leaving Water temperature from the unit, this value will be available only the RPS sensor is available.
- The “EWF” shows the Entering Water flow to the unit, this value will be available only the VFS sensor is available.
- The “LWP” shows the Leaving Water pressure (Return Water) from the unit, this value will be available only the RPS sensor is available.

There are Two Power sources are available in the system POWER A and POWER B

- IF the Power is available, display shows as Green.

- IF the Power is not available, display shows as Red.

⚡ Power Status		
NAME	ADDRESS	VALUE
● ⚡ Power A	9110	●
● ⚡ Power B	9111	●

Figure 106. Power Status

## Control settings

The control page is protected by password, when pressing the Control tab below pop will be displayed. The password is 8080.




Figure 107. Sign In

## ⓧ Temperature Settings

ADDRESS	NAME	VALUE	UNIT
16384	ⓧ Room Temperature sp	24	°C
16388	ⓧ Air In Max	45	°C
16390	⤵ Air In Differential	1	K
16392	⤵ Air Out Setpoint	23	°C
16398	⤵ Air Out Differential	1	K

Figure 108. Temperature Settings

- The Room & Air in Temperature parameters are used to control the fan speed.
- The difference between Room temperature and Air in Temperature setpoint range over which fan will go from minimum speed and maximum speed.
- The Air Out Temperature parameters are used to control the Valve open/close.
- The differential values are used to calculate the minimum and maximum temperature values that unit must be operated.

## Fan Control

NAME	ADDRESS	CONTROL
Fan Minimum Speed (%)	16400	30
Fan Maximum Speed (%)	16445	100
Fan Initial Speed (%)	16405	30
Fan Differential Delay (Sec)	16402	30
Fan 1	16472	 ON
Fan 2	16473	 ON
Fan 3	16474	 ON
Fan 4	16475	 ON
Fan 5	16476	 ON
Fan 6	16477	 ON

Figure 109. Fan Control

- The fans are controlled by the temperature on the front of RDHx and back side of IT Equipment.
- The fan parameters can be varied depending on equipment and operation parameters.
- The Fan Minimum speed is the speed a fan operates at when Air in temperature below the Room temperature setpoint.
- In startup all the fans operate at Initial speed.
- The Fan Maximum speed will have been set at site based on the expected maximum speed that unit transfers the heat from the RDHx.
- Fan differential delay is ensuring the fan speed modulation periodically to avoid the false results.
- Number of Fans can be enabled based on-Site requirements, by default all the fans are active(true).
- If Fan is not activated, the alarms of the corresponding fan also do not activate.

## Valve Control

PARAMETER	ADDRESS	VALUE
Valve Minimum Open (%)	16396	15
Valve Maximum Open (%)	16394	70
Valve Initial Open (%)	16446	30
Valve Differential Delay (Sec)	16401	180

Figure 110. Valve Control

- The valve is controlled purely by the Air Out temperature
- The Valve Minimum Open is the position when Air Out temperature is below the setpoint.
- In startup all the valve opens at Initial Open position, this can adjust at site conditions.
- The Valve Maximum open will have been set at site based on the expected maximum speed that unit


transfers the heat from the RDHx.

- Valve differential delay is ensuring the valve opening periodically to avoid the false results.

## Factory setting

The control page is protected by password, when pressing the Factory tab below pop will be displayed.

The password is 9090.



**Figure 111. Password Interface**

## ⚙️ Factory Settings

ADDRESS	NAME	VALUE
16407	Fan Minimum Rpm	0
16408	Fan Maximum Rpm	2600
16409	Valve Minimum Open	0
16410	Valve Maximum Open	10000
16411	Fan Offset Value	20
16412	Valve Offset Value	20

**Figure 112. Factory Setting**

- Fan minimum Rpm & Fan Maximum Rpm are the parameters of fan, it can be modified at site operations, so that modulation will happen within this set values.
- Valve minimum Open & Valve Maximum Open are the parameters of valve, it can be modified at site operations, so that valve position modulation will happen with in this set values.
- Fan offset & Valve offset are the Offset parameters to decide the ratio of fan speed and valve opening modulations.

## Leakage Sensor Settings

16413	Water Leakage Sensor	 ON
16414	Leakage fault Delay (Sec)	<input type="text" value="25"/>
16415	Leakage notification cycle	<input type="text" value="3"/>
16468	Fan Ramp Modulation Change	 OFF
16480	Leakage Action Modulation	 OFF

**Figure 113. Leakage Sensor Settings**

- Water Leakage sensor to activate the leakage sensor function normally is an optional sensor.
- The delay and notification count that decides if the leakage happens during the operation and creates an alarm as leakage fault.
- Fan Ramp Modulation is an Option to change fan modulation (Optional)

## Water Sensor Settings

16496	Valve Placement Line	 Return
16478	VFS Active	 OFF
16479	RPS Active	 OFF
16488	EPIV	 OFF
16495	EV Enable	 OFF
16489	Vnom	<input type="text" value="1"/>
16491	Unit factor	<input type="text" value="0"/>

**Figure 114. Water Sensor Settings**

- VFS is a sensor used to monitor the Water In supply (Entering Water) Temperature and Flow rate.
- RPS is a sensor used to monitor the Return water (Leaving Water) Temperature and Pressure.
- If the above options (VFS and RPS) are not enabled, the functions of sensor will not be functioned.
- EPIV is a parameter to enable the EPIV valve, then RPS is need to enable the RPS is used.
- EV Enable is a parameter to enable the EV valve, if it is enabling remaining selection option will reset to default.
- Vnom & Unit factor parameters are used to calculate the actual flow and temperature according to the valve models used (applicable for EPIV &EV).

## Program Control settings

### Program Control

Address	Name	Value	Um
16416	Fan Scale Min (%)	0	
16417	Fan Scale Max (%)	100	
16418	Valve scale Min (%)	0	
16419	Valve Scale Max (%)	100	
16456	Fan Offset Mul Factor (%)	4	
16455	Valve Offset Mul Factor (%)	4	
16420	Temp Alarm Bypass	False	
16421	Fan Alarm Bypass	False	
16422	Valve Alarm Bypass	False	
16423	Water Leakage Bypass	False	
16424	System Reset	False	

**Figure 115. Program Control**

Basically, program settings are applicable for Manufacturers, Password protected.

## Common settings

### Metric Selection

NAME	ADDRESS	VALUE
° Celsius / Fahrenheit	16428	 °C
Bar/Psi	16447	 Bar
Lpm/Gpm	16448	 Lpm

**Figure 116. Metric Selection**

Metric selection provides the options to change the units

By default, temperature units are Celsius °C, this can change to Fahrenheit.

By default, pressure units are Bar, this can change to Psi.

By default, Water flow units are Lpm, this can change to Gpm.

## Network Settings

- The RDHx is delivered with default Ip Address of 10.0.0.100 or 192.168.0.100 and sub net is 255.255.255.0.
- Ip address and other network details can be edited as per the site network requirement.
- The other method of assigning Ip details is enabled the Automatic DCHP method, once the DCHP option is enabled automatically Ip details will assign as per the network connection so the same can be used for other integrations.

### Network Settings

NAME	ADDRESS	STATUS
Automatic DCHP	15818	 OFF
Ip_1_Current	15798	10
Ip_2_Current	15799	0
Ip_3_Current	15800	0
Ip_4_Current	15801	100
SubMask_1_Current	15806	255
SubMask_2_Current	15807	255
SubMask_3_Current	15808	255
SubMask_4_Current	15809	0
Gateway_1_Current	15802	10
Gateway_2_Current	15803	0
Gateway_3_Current	15804	0
Gateway_4_Current	15805	1
DNS_1_Current	15810	8
DNS_2_Current	15811	8
DNS_3_Current	15812	8
DNS_4_Current	15813	8

Figure 117. Network Settings

## Date & Time settings

 Date & Time Settings

**PLC Date:** Address: 8750, 8749, 8748

<b>Year</b> 23	<b>Month</b> 8	<b>Day</b> 7
-------------------	-------------------	-----------------

**PLC Time:** Address: 8746, 8745, 8744

<b>Hours</b> 0	<b>Minutes</b> 0	<b>Seconds</b> 0
-------------------	---------------------	---------------------

**Controller Apply** Address: 8751

**APPLY**

Figure 118. Date & Time

- The RDHx controller has internal date/time memorizing capabilities, but sometimes it necessary to adjust Date/ Time based on region/Zone changes.
- Enter the present Date/Time if it necessary and press the Controller Apply button in the above screen so that actual Date/Time will update to controller, the same timing will follow.
- If the HMI display shows the incorrect Date/Time, then press the Display apply button to adjust the actual Date/Time to Display.
- Parameter enables the preventive maintenance warning notification from the date of selection (Q. Yearly or H. Yearly or Yearly). It's mandatory to select a period to enable PM warning of unit.

 Preventive Maintenance Settings

**Q. Yearly:** Address: 16425  OFF

**H. Yearly:** Address: 16426  OFF

**Yearly:** Address: 16427  OFF

**Reset PM Settings:** Address: 09133  OFF

Figure 119. PM Settings

- Q. Yearly: Every 3 Months from the date of selection warning will be displayed.
- H. Yearly: Every 6 Months from the date of selection warning will be displayed.
- Yearly: Every 12 Months from the date of selection warning will be displayed.
- PM Reset is reset the current period of PM setting, if necessary, only for Maintenance purpose of unit.
- After the PM activity, need to again enable the PM1parameter for next cycle.

**Installation Date:** Address: 16471, 16470, 16469

<b>Year</b> 0	<b>Month</b> 0	<b>Day</b> 0
------------------	-------------------	-----------------

Figure 120. Installation Details

Installation details are an option to enter the Installation date for calculate the number of days from the installation date.

## Manual Testing

### ⚙ Mode Selection & Valve Test

#### ⌚ Mode Selection

ADDRESS	NAME	VALUE
9075	👉 Manual Mode	 OFF

**Figure 121. Mode Selection**

Note: Manual Mode operates only when the unit is “OFF” condition. After testing completes its mandatory to select “Off” so that system will function in “Auto Mode”

- Press “On” to Enable the Manual Mode.

### ⚙ System Parameters

NAME	ADDRESS	VALUE
👉 Fan 1 Speed (%)	9076	<input type="text" value="0"/>
👉 Fan 1 Stop	9049	 OFF
👉 Fan 2 Speed (%)	9077	<input type="text" value="0"/>
👉 Fan 2 Stop	9050	 OFF
👉 Fan 3 Speed (%)	9078	<input type="text" value="0"/>
👉 Fan 3 Stop	9051	 OFF
👉 Fan 4 Speed (%)	9079	<input type="text" value="0"/>
👉 Fan 4 Stop	9052	 OFF
👉 Fan 5 Speed (%)	9080	<input type="text" value="0"/>
👉 Fan 5 Stop	9053	 OFF
👉 Fan 6 Speed (%)	9081	<input type="text" value="0"/>
👉 Fan 6	9054	 OFF

**Figure 122. Fan Test**

- Manual fan test possible here, Set the required speed (10 % to 100%) the fan will start running in manual mode.
- Select the Fan turn to “Off” to stop the fan in manual mode.

- Select the Fan turn to “On” and enter “0” in fan speed Field. So that fan will not be running.

Valve Test		
ADDRESS	NAME	VALUE
9082	٪ Valve Command (%)	<input type="text" value="40"/>
9086	■ Valve Stop	<input type="button" value="OFF"/>

**Figure 123. Valve Test**

- Manual Valve test possible here, Set the required opening command (10 % to 100%) the valve will start opening in manual mode.
- Select the Valve stop to “Off” to stop the valve in manual mode.
- Select the valve stop to “On” and enter “0” in valve command. So that valve will be fully closed.

## IO Status

- The IO status of Analog & Digital is used to monitor the healthy and working conditions of hardware devices which are used in RDHx.

### ↳ IO Status-Analog

NAME	ADDRESS	VALUE	UNIT
🌡 AI1.Air In NTC-1	9097	<input type="text" value="316"/>	°C
🌡 AI1.Air In NTC-2	9098	<input type="text" value="316"/>	°C
🌡 AI1.Air In NTC-3	9099	<input type="text" value="316"/>	°C
🌡 AI1.Air In NTC-4	9100	<input type="text" value="316"/>	°C
🌡 AI1.Air Out NTC-5	9101	<input type="text" value="315"/>	°C
🏡 AI6.Room	9102	<input type="text" value="315"/>	°C
💧 AI9.Water Supply	9105	<input type="text" value="0"/>	°C
💧 AI10.Water Supply	9106	<input type="text" value="0"/>	°C
💧 AI11.ReturnWater	9107	<input type="text" value="0"/>	°C
⌚ AI12.ReturnWaterPress.	9108	<input type="text" value="0"/>	bar

**Figure 125. IO Status - Analog**

**Figure 124. IO Status - Digital**

## Alarm Settings

### ① Alarm Threshold Setting

ADDRESS	NAME	VALUE	UNIT
16449	A1 : Air In Temp Low	20	°C
16451	A2 : Air In Temp High	60	°C
16429	A3 : Air Out Temp Low	17	°C
16431	A4 : Air Out Temp High	27	°C
16433	A5 : Water In Temp Low	15	°C
16435	A6 : Water In Temp High	25	°C

Figure 126. Alarm Setting (A1~A6)

16437	A7 : Water Out Temp Low	15	°C
16439	A8 : Water Out Temp High	40	°C
16441	A9 : Fan speed Threshold	2	%
16442	A10 : Fan speed Threshold Delay	30	Sec
16443	A11 : Valve Fbk Threshold	2	%
16444	A12 : Valve Fbk Threshold Delay	30	Sec
16386	A13 : Rack In Temp Low	17	°C
16453	A14 : Rack In Temp High	27	°C
16460	A15 : Water In Flow Low	10	L/min
16462	A16 : Water In Flow High	140	L/min
16464	A17 : Return Water Pressure Low	2	bar
16466	A18 : Return Water Pressure High	6	bar

Figure 127. Alarm Setting (A7~A18)

- A1 & A2 Setup an Alarm to indicate the Air In temperature at the front of the unit that reaches preset temperature.
- A3 & A4 Setup an Alarm to indicate the Air Out temperature at the back of the rack reaches preset temperature.
- A5 & A6 Setup an Alarm to indicate the Water In temperature to the unit that reaches preset temperature. (Only applicable for VFS sensor availability).
- A7 & A8 Setup an Alarm to indicate the Return Water temperature from the unit that reaches preset temperature. (Only applicable for RPSS sensor availability)
- A9 is a Fan threshold value, when the fan run command and actual running feedback are not in the range of threshold % then the fan threshold not in range alarm will appear. A10 is a delay that waits for a time to monitor Fan modulation.
- A11 is a Valve threshold value, when the valve opening command and actual opened feedback are not in the range of threshold % then the valve threshold not in range alarm will appear. A12 is a delay that waits for a time to monitor valve modulation.
- A13 & A14 Setup an Alarm to indicate the Room temperature at the front of the rack reaches preset temperature.

- A15 & A16 Setup an Alarm to indicate the Water In flow rate to the unit that reaches preset value. (Only applicable for VFS sensor availability).
- A17 & A18 Setup an Alarm to indicate the Return Water pressure from the unit that reaches preset value. (Only applicable for RPS sensor availability).

ALARM	MESSAGE
A01	A01 : Valve Communication Fault - ACTIVE
A02	A02 : Fan1 Communication Fault - ACTIVE
A03	A03 : Fan2 Communication Fault - ACTIVE
A04	A04 : Fan3 Communication Fault - ACTIVE
A05	A05 : Fan4 Communication Fault - ACTIVE
A06	A06 : Fan5 Communication Fault - ACTIVE
A07	A07 : Fan6 Communication Fault - ACTIVE
A08	A08 : Power Source A fault - ACTIVE
A09	A09 : Power Source B fault - ACTIVE
A10	A10 : Air In Temp Sensor 1 failed - ACTIVE
A11	A11 : Air In Temp Sensor 2 failed - ACTIVE
A12	A12 : Air In Temp Sensor 3 failed - ACTIVE
A13	A13 : Air In Temp Sensor 4 failed - ACTIVE
A14	A14 : Room Temperature sensor Failed - ACTIVE
A16	A16 : AirOut Temperature Sensor Failed - ACTIVE

**Figure 128. Alarm Notifications**

## SNMP Module configuration.

### Default Access Details

Default IP Address: 192.168.1.3

Configuration Port: 444

Access URL: 192.168.1.3:444

Username: admin

Password: INOVA\_123456




Figure 129. Sign in

### Network Configuration

1. Log in to the SNMP module using the above credentials.
2. From the Home Screen, navigate to “Network Settings”.





Figure 130. Network Settings

3. Under Ethernet Settings, choose one of the following:
  - DHCP (if IP assignment is handled by the customer network), or
  - Static IP and enter the required IP address, subnet mask, and gateway as per the customer network.
4. Click Apply.

## PLC and Modbus TCP Configuration

1. From the Home toolbar, navigate to “PLC and VPN”.
2. In the Modbus TCP section, enter the Main PC IP address.
3. Click Apply to enable communication between the PLC/PC and the SNMP module.



Modbus TCP settings

Communication parameters

Port: 502

Timeout (ms): 500

IP addresses allow list

		<input type="button" value="Add address"/>
192.168.1.50	255.255.255.0	<input type="button" value=""/>

Figure 131. PLC and VPN

## Web Page Access

The SNMP web interface using the configured IP address:

<SNMP\_IP\_Address> (Default IP: 192.168.1.3)

Login Credentials:

Username: admin

Password: INOVA\_123456



Username:

Password:

Figure 132. Login

## Available Web Pages

After successful login, the following pages are available:




Figure 133. Control Status




Figure 134. Unit Control and Power Status




Figure 135. Fan Status and Water Status

## Control Page

### 0° Temperature Settings

ADDRESS	NAME	VALUE	UNIT
16384	0° Room Temperature sp	80.00	°F
16388	0° Air In Max	114.80	°F
16390	↔ Air In Differential	1.00	°F
16392	🌡 Air Out Setpoint	79.00	°F
16398	☒ Air Out Differential	1.00	°F

### Dp Sensor Settings

NAME	VALUE	UM
dP Sensor Enable	True	▼
dP Setpoint	0.50	
dP Deadband	0.01	
dP kpi	0.50	
dP Ti	10	
dP Range - Min	-0.40	
dP Range - Max	0.40	

Figure 136. Temperature Settings and Sensor Settings

### Fan Control

	ADDRESS	CONTROL
↳ Fan Minimum Speed (%)	16400	20
↳ Fan Maximum Speed (%)	16445	100
↳ Fan Initial Speed (%)	16405	20
↳ Fan Differential Delay (Sec)	16402	30
↳ Fan 1	16472	<input checked="" type="button"/> ON
↳ Fan 2	16473	<input checked="" type="button"/> ON
↳ Fan 3	16474	<input checked="" type="button"/> ON
↳ Fan 4	16475	<input checked="" type="button"/> ON
↳ Fan 5	16476	<input checked="" type="button"/> ON
↳ Fan 6	16477	<input checked="" type="button"/> ON

### Valve Control

	ADDRESS	VALUE
↳ Valve Minimum Open (%)	16396	5.00
↳ Valve Maximum Open (%)	16394	100.00
↳ Valve Initial Open (%)	16446	20
⌚ Valve Differential Delay (Sec)	16401	180

Figure 137. Fan Control and Valve Control

## Factory Setting

### Factory Settings

ADDRESS	NAME	VALUE
16487	Fan Minimum Rpm	0
16488	Fan Maximum Rpm	2600
16489	Valve Minimum Open	0
16410	Valve Maximum Open	10000
16411	Fan Offset Value	20
16412	Valve Offset Value	20
16413	Water Leakage Sensor	<input checked="" type="checkbox"/> ON
16414	Leakage fault Delay (Sec)	25
16415	Leakage notification cycle	3
16468	Fan Ramp Modulation Change	<input checked="" type="checkbox"/> OFF
16480	Leakage Action Modulation	<input checked="" type="checkbox"/> OFF
16496	Valve Placement Line	<input checked="" type="checkbox"/> Supply
16478	VFS Active	<input checked="" type="checkbox"/> OFF
16479	RPS Active	<input checked="" type="checkbox"/> ON
16488	EPIV Enable	<input checked="" type="checkbox"/> ON
16495	EV Enable	<input checked="" type="checkbox"/> OFF
16489	Vnom	1.00
16491	Unit factor	0.01

### Fan Replace

ADDRESS	NAME	VALUE
9083	Fan Address (2..7)	0
9085	Fan Address Confirm	<input checked="" type="checkbox"/> OFF

Figure 138. Factory Setting

### Restore fan to factory setup

ADDRESS	NAME	VALUE
9153	Reset Fan Address to default(2..7)	0
9155	Fan Address Reset	<input checked="" type="checkbox"/> OFF

### Air In Sensor Bypass

ADDRESS	NAME	VALUE
16481	AIR In Sensor -1	<input checked="" type="checkbox"/> ON
16482	AIR In Sensor -2	<input checked="" type="checkbox"/> ON
16483	AIR In Sensor -3	<input checked="" type="checkbox"/> ON
16484	AIR In Sensor -4	<input checked="" type="checkbox"/> ON
9160	AIR In Sensor Online	4
9172	AIR In Sensor bypass	true

Figure 140. Air In Sensor Bypass

Figure 139. Restore Fan to Factory Setup

## Common setting page

**Metric Selection**

ADDRESS	NAME	VALUE
16428	<input type="checkbox"/> Celsius / Fahrenheit	<input checked="" type="checkbox"/> F
16447	<input type="checkbox"/> Bar/Psi	<input checked="" type="checkbox"/> Psi
16448	<input type="checkbox"/> Lpm/Gpm	<input checked="" type="checkbox"/> Gpm
16529	<input type="checkbox"/> Pa/Wc	<input checked="" type="checkbox"/> Wc

Figure 141. Metric Selection

## Date & Time

**Date & Time Settings**

**PLC Date:**  
Address: 8750, 8749, 8748

Year	Month	Day
26	1	12

**PLC Time:**  
Address: 8746, 8745, 8744

Hours	Minutes	Seconds
11	10	25

**Controller Apply**

**APPLY**

**Preventive Maintenance Settings**

Q.Yearly: Address: 16425  OFF

H.Yearly: Address: 16426  OFF

Yearly: Address: 16427  OFF

Reset PM Settings: Address: 9133  OFF

**Installation Date:**  
Address: 16457, 16458, 16459

Year	Month	Day
2026	1	1

Figure 143. Date & Time Settings

Figure 142. Preventive Maintenance Settings

## Manual page

**Mode Selection**

ADDRESS	NAME	VALUE
9075	<input type="checkbox"/> Manual Mode	<input checked="" type="checkbox"/> OFF

**Valve Test**

ADDRESS	NAME	VALUE
9082	<input type="checkbox"/> % Valve Command (%)	40
9086	<input checked="" type="checkbox"/> Valve Stop	<input type="checkbox"/> OFF

**System Parameters**

ADDRESS	NAME	VALUE
9076	<input type="checkbox"/> Fan 1 Speed (%)	0
9049	<input type="checkbox"/> Fan 1 Stop	<input checked="" type="checkbox"/> OFF
9077	<input type="checkbox"/> Fan 2 Speed (%)	0
9050	<input type="checkbox"/> Fan 2 Stop	<input checked="" type="checkbox"/> OFF
9078	<input type="checkbox"/> Fan 3 Speed (%)	0
9051	<input type="checkbox"/> Fan 3 Stop	<input checked="" type="checkbox"/> OFF
9079	<input type="checkbox"/> Fan 4 Speed (%)	0
9052	<input type="checkbox"/> Fan 4 Stop	<input checked="" type="checkbox"/> OFF
9080	<input type="checkbox"/> Fan 5 Speed (%)	0
9053	<input type="checkbox"/> Fan 5 Stop	<input checked="" type="checkbox"/> OFF
9081	<input type="checkbox"/> Fan 6 Speed (%)	0

Figure 145. Mode Selection

Figure 144. System Parameters

## IO page




Figure 147. IO Status Analog

Figure 146. IO Status-Digital

## Alarm Setting page

### ▲ Alarm Threshold Setting

ADDRESS	NAME	VALUE	UNIT
16449	① A1 : Air In Temp Low	68.00	°F
16451	① A2 : Air In Temp High	140.00	°F
16429	① A3 : Air Out Temp Low	60.00	°F
16431	① A4 : Air Out Temp High	82.00	°F
16433	② A5 : Water In Temp Low	60.00	°F
16435	② A6 : Water In Temp High	80.00	°F
16437	② A7 : Water Out Temp Low	60.00	°F
16439	② A8 : Water Out Temp High	105.00	°F
16441	④ A9 : Fan speed Threshold	2	%
16442	⑤ A10 : Fan speed Threshold Delay	30	Sec
16443	⑥ A11 : Valve Fbk Threshold	2	%
16444	⑦ A12 : Valve Fbk Threshold Delay	30	Sec
16386	⑧ A13 : Rack In Temp Low	75.00	°F
16453	⑧ A14 : Rack In Temp High	82.00	°F
16460	⑨ A15 : Water Flow Low	1.50	Gpm
16462	⑨ A16 : Water Flow High	36.99	Gpm
16464	⑩ A17 : Water Press Low	29.01	PSI
16466	⑩ A18 : Water Press High	87.02	PSI
16536	⑪ A19 : dP Alarm Delay	60	Sec
16540	⑪ A20 : dP Actual Low	0.00	WC
16542	⑪ A21 : dP Actual High	0.36	WC
16544	⑫ A22 : dP Sensor Low	-0.36	WC
16546	⑫ A23 : dP Sensor High	0.36	WC
16550	⑬ A24 : Valve Comm Delay	60	Sec
16551	⑬ A25 : Fan Comm Delay	60	Sec

**Figure 148. Alarm Threshold Setting**

## Notification page

Notification		<span style="color: green;">C</span> ALARM RESET
ALARM	MESSAGE	
A01	A01 : Valve Communication Fault - ACTIVE	
A02	A02 : Fan1 Communication Fault - ACTIVE	
A03	A03 : Fan2 Communication Fault - ACTIVE	
A04	A04 : Fan3 Communication Fault - ACTIVE	
A05	A05 : Fan4 Communication Fault - ACTIVE	
A06	A06 : Fan5 Communication Fault - ACTIVE	
A07	A07 : Fan6 Communication Fault - ACTIVE	

Figure 149. Notification

## Sensor Calibration page

□ Sensor Calibration

ADDRESS	NAME	VALUE
9192	<input type="checkbox"/> Sensor Select	<input style="border: 1px solid #ccc; padding: 2px 10px; width: 100px; height: 20px; border-radius: 5px;" type="button" value="0 None"/>
9190	<input type="checkbox"/> Sensor Read Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9194	<input type="checkbox"/> Required Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9186	<input type="checkbox"/> Offset Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9184	<input type="checkbox"/> Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
16511	<input type="checkbox"/> Gain	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="1.00"/>
9193	<input type="checkbox"/> Confirm	<span style="color: red;">OFF</span>

Figure 151. Sensor Calibration

□ Sensor Status

ADDRESS	NAME	VALUE
9196	<input type="checkbox"/> Air In Temp-1	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9198	<input type="checkbox"/> Air In Temp-2	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9200	<input type="checkbox"/> Air In Temp-3	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9202	<input type="checkbox"/> Air In Temp-4	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9204	<input type="checkbox"/> Air Out Temp	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9206	<input type="checkbox"/> Room Temp	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="0.00"/>
9242	<input type="checkbox"/> dP sensor	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="-0.40"/>
8994	<input type="checkbox"/> Air In Temp-1 - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="32.00"/>
8996	<input type="checkbox"/> Air In Temp-2 - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="32.00"/>
8998	<input type="checkbox"/> Air In Temp-3 - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="32.00"/>
9000	<input type="checkbox"/> Air In Temp-4 - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="32.00"/>
9002	<input type="checkbox"/> Air Out Temp - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="32.00"/>
9004	<input type="checkbox"/> Room Temp - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="32.00"/>
9220	<input type="checkbox"/> dP Actual value - Corrected Value	<input style="width: 100px; height: 20px; border: 1px solid #ccc; border-radius: 5px;" type="text" value="-0.40"/>

Figure 150. Sensor Status

## System Info page

i System Info

ADDRESS	NAME	VALUE
9236	PLC Version	XAI-1.0
9144-9149	MAC Address	00:18:BB:06:2D:AC

Figure 152. System Info

## Part VII. Maintenance and Troubleshooting

### Weekly Checks

- Visual Inspection: Inspect the unit for any visible signs of wear, leaks, or corrosion.
- Leak Detection Sensor: Verify the operation of the leakage detection sensor. Ensure that it is free of obstructions and that the signal response is functioning correctly.
- Cooling System Status: Check the coolant flow rate and water pressure to ensure they are within the recommended operating range.

### Monthly Maintenance

- Fan Operation Check: Inspect and test the EC fans to ensure smooth operation. Check for unusual vibrations or noise that may indicate wear or imbalance.
- Control Panel Functionality: Verify the response of the control panel buttons and the accuracy of displayed readings. Ensure all LED indicators and status alarms are functioning correctly.
- Piping and Connections: Inspect all water pipes, hoses, and fittings for signs of wear, corrosion, or leaks. Ensure that connections are tight and that there are no blockages.

### Quarterly Checks

- Internal Components Inspection: Open the unit (if safe to do so) and inspect internal components such as the heat exchanger and fans for dust accumulation or damage.
- Electrical Connections: Check all electrical connections for proper tightness and insulation. Ensure that power feeds (A & B) are connected securely and show no signs of wear or deterioration.
- Calibration and Adjustment: Calibrate the temperature sensors, flow rate sensors, and other monitoring devices to ensure accurate performance readings.

### Annual Maintenance

- Comprehensive System Check: Perform a comprehensive review of the entire system, ensuring that all components are in good working condition and have no potential points of failure.
- Fan and Valve Maintenance: Conduct a thorough inspection of the fans, motors, and valves, replacing any parts that are worn or damaged.
- System Software Update: Ensure that the unit's firmware and software are up to date with the latest improvements and security patches.

# Cleaning and Water Quality Management

## Cleaning Guidelines

- Fan Cleaning: Periodically clean the EC fans using a soft brush or compressed air to remove any dust or debris that may obstruct airflow. Ensure that fans are powered off before cleaning.
- Heat Exchanger Cleaning: Use appropriate cleaning solutions (non-corrosive) to clean the heat exchanger surface. Ensure the solution does not damage the fins or interfere with heat transfer efficiency.
- Control Panel Cleaning: Clean the control panel and surrounding areas using a dry cloth. Avoid using abrasive materials that may scratch or damage the display.
- Exterior Surface Cleaning: Wipe down the unit's exterior with a soft cloth dampened with water and mild detergent. Avoid harsh chemicals that may degrade the unit's finish.

## Water Quality Management

- Water Quality Monitoring: Regularly test the water quality in the cooling system. Check for pH levels, conductivity, and contaminant concentrations. Ensure that water is free from minerals that can cause scaling or corrosion.
- Water Treatment: If necessary, treat the water with a suitable cooling water additive to prevent corrosion, scaling, and microbiological growth.
- Water Filter Maintenance: If the system is equipped with filters, inspect and clean or replace them at regular intervals as recommended by the manufacturer.
- Water Chemistry Adjustment: Regularly adjust the water chemistry to maintain proper water hardness and alkalinity. This will ensure the longevity of internal components and improve overall system efficiency.

## Alarms & Trouble shooting

**Table 14. Alarm & Trouble shooting**

Code	Description	Causes	Solution
A01	Valve Communication Fault	1.NO communication between Controller & Valve. 2.RS 485 Communication Lost	1.Make sure the Valve power 24V DC cable "A 17" connected correct way in "J1" Connector.  2.Make sure the Communication cable "A17" connected correct way in "J1" Connector.
A02	Fan1 Communication Fault	1.NO communication between controller & Fan 1. 2.RS 485 Communication Lost	1.Make sure the Fan 1 single phase power connection cable "A11" in "J21" Connector.  2.Make sure the Communication cable "A05_1" connected correct way in "J21" Connector.
A03	Fan2 Communication Fault	1.NO communication between controller & Fan 2. 2.RS 485 Communication Lost	1.Make sure the Fan 2 single phase power connection cable "A12" in "J22" Connector.  2.Make sure the Communication cable "A05_2" connected correct way in "J22" Connector.
A04	Fan3 Communication Fault	1.NO communication between controller & Fan 3. 2.RS 485 Communication Lost	1.Make sure the Fan 3 single phase power connection cable "A13" in "J23" Connector.  2.Make sure the Communication cable "A05_3" connected correct way in "J23" Connector.
A05	Fan4 Communication Fault	1.NO communication between controller & Fan 4. 2.RS 485 Communication Lost	1.Make sure the Fan 4 single phase power connection cable "A14" in "J24" Connector.  2.Make sure the Communication cable "A05_4" connected correct way in "J24" Connector.
A06	Fan5 Communication Fault	1.NO communication between controller & Fan 5. 2.RS 485 Communication Lost	1.Make sure the Fan 5 single phase power connection cable "A15" in "J25" Connector.  2.Make sure the Communication cable "A05_5" connected correct way in "J25" Connector.

A07	Fan6 Communication Fault	1.NO communication between controller & Fan 6. 2.RS 485 Communication Lost	1.Make sure the Fan 6 single phase power connection cable "A16" in "J26" Connector.  2.Make sure the Communication cable "A05_6" connected correct way in "J26" Connector.
A08	Power Source A fault	1.NO incoming power source 200V – 240V AC in C19/20 connector	1. Make sure the power source is available in power A connector  2. Make sure FU1, FU2 is healthy  3. Make sure relay KA1 is healthy
A10	In Temp Sensor 1 failed	1.Air In temperature sensor 1 failed to send the values	1. Make sure the temperature sensor "U1-TS1" physically not damaged.  2. Make sure the "U1-TS1" cable connected correct way in "J2" connector.  3. Make sure the "CAN 5" connector connected properly in controller.
A11	In Temp Sensor 2 failed	1.Air In temperature sensor 2 failed to send the values	1. Make sure the temperature sensor "U2-TS2" physically not damaged.  2. Make sure the "U2-TS2" cable connected correct way in "J2" connector.  3. Make sure the "CAN 5" connector connected properly in controller.
A12	In Temp Sensor 3 failed	1.Air In temperature sensor 3 failed to send the values	1. Make sure the temperature sensor "B1-TS3" physically not damaged.  2. Make sure the "B1-TS3" cable connected correct way in "J2" connector.  3. Make sure the "CAN 5" connector connected properly in controller.

A13	In Temp Sensor 4 failed	1.Air In temperature sensor 4 failed to send the values	<ol style="list-style-type: none"> <li>1. Make sure the temperature sensor "B2-TS4" physically not damaged.</li> <li>2. Make sure the "B2-TS4" cable connected correct way in "J2" connector.</li> <li>3. Make sure the "CAN 5" connector connected properly in controller.</li> </ol>
A14	Room Temperature sensor Failed	1.Room temperature sensor failed to send the values	<ol style="list-style-type: none"> <li>1. Make sure the Room temperature sensor "TS6" physically not damaged.</li> <li>2. Make sure the "TS6" cable connected correct way in "J2" connector.</li> <li>3. Make sure the "CAN 5" connector connected properly in controller.</li> </ol>
A15	Room Humidity Sensor Failed (Spare)	1.Room humidity sensor failed to send the values	<ol style="list-style-type: none"> <li>1. Make sure the Room humidity sensor "TS7" physically not damaged.</li> <li>2. Make sure the "TS7" cable connected correct way in "J2" connector.</li> <li>3. Make sure the "CAN 5" connector connected properly in controller.</li> </ol>
A16	Air Out Temperature Sensor Failed	1.Air Outlet temperature sensor failed to send the values	<ol style="list-style-type: none"> <li>1. Make sure the outlet temperature sensor "TS5" physically not damaged.</li> <li>2. Make sure the "TS5" cable connected correct way in "J2" connector.</li> <li>3. Make sure the "CAN 5" connector connected properly in controller.</li> </ol>
A17	In Water Flow Sensor Failed	1.The VFS sensor failed to send the values.	<ol style="list-style-type: none"> <li>1. Make sure the VFS sensor is physically not damaged.</li> <li>2. Make sure the 5V dc cable "A20" connected correct way in "J3" connector.</li> <li>3. Make sure the signal transmission cable "A20" connected correct way in "J3" connector.</li> <li>4. Make sure the "CAN 13" connector connected properly in controller.</li> </ol>

A18	In Water Temperature Sensor Failed	1.The VFS sensor failed to send the values.	<ol style="list-style-type: none"> <li>1. Make sure the VFS sensor is physically not damaged.</li> <li>2. Make sure the 5V dc cable "A20" connected correct way in "J3" connector.</li> <li>3. Make sure the signal transmission cable "A20" connected correct way in "J3" connector.</li> <li>4. Make sure the "CAN 13" connector connected properly in controller.</li> </ol>
A19	Return Water Temperature Sensor Failed	1.The RPS sensor failed to send the values.	<ol style="list-style-type: none"> <li>1. Make sure the RPS sensor is not damaged physically.</li> <li>2. Make sure the 5V dc cable "A21" connected correct way in "J3" connector.</li> <li>3. Make sure the signal transmission cable "A21" connected correct way in "J3" connector.</li> <li>4. Make sure the "CAN 13" connector connected properly in controller.</li> </ol>
A21	Air In Temperature is High	1.Actual Air in temperature is higher than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure all the fans are running as per the values which are displayed on the status screen. Not below the displayed values.</li> <li>3.If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A22	Air In Temperature is Low	1.Actual Air in temperature is lower than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure all the fans are running as per the values which are displayed on the status screen. Not maximum the displayed values.</li> <li>3.If above points are ok then press the Alarm Ack button in HMI.</li> </ol>

A23	Air Out Temperature is High	<p>1. Actual Air out temperature is higher than the set value.</p>	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure the valve is running as per the values which are displayed on the status screen.</li> <li>3. Make sure proper water flow is available.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A24	Air Out Temperature is Low	<p>1. Actual Air out temperature is lower than the set value.</p>	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure the valve is running as per the values which are displayed on the status screen.</li> <li>3. Make sure proper water flow is available.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A25	Room Temperature is High	<p>1. Actual room temperature (Rack In) is higher than the set value.</p>	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure room infra temperature like AC or centralizing system.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A26	Room Temperature is Low	<p>1. Actual room temperature (Rack In) is lower than the set value.</p>	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure room infra temperature like AC or centralizing system.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>

A27	Air In Process Temperature High	If fan is running at high speed still actual air in temperature is higher than the set value, then this fault occurs.	<ol style="list-style-type: none"> <li>1. Make sure all the fans are running as per the command</li> <li>2. Make sure the temperature sensors are functioning properly.</li> <li>3. If server is running as higher temperature then adjust the "Room temperature setpoint" in control-temperature screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A28	Air In Process Temperature Low	If fan is running at minimum speed still actual air in value is lower than the set value, then this fault occurs.	<ol style="list-style-type: none"> <li>1. Make sure all the fans are running as per the command</li> <li>2. Make sure the temperature sensors are functioning properly.</li> <li>3. If server is running as lower temperature then adjust the "Room temperature setpoint" in control-temperature screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A29	Air Out Process Temperature High	If valve is maximum open still actual air outlet temperature is higher than the set value, then this fault occurs.	<ol style="list-style-type: none"> <li>1. Make sure the valve is open as per the command</li> <li>2. Make sure the outlet temperature sensor is functioning properly.</li> <li>3. Make sure there is enough water supplied to the unit. If it requires adjust the "Air out temperature set point" in Control – Temperature Screen</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A30	Air Out Process Temperature Low	If valve is minimum open and the actual air outlet temperature is lower than the set value, then this fault occurs.	<ol style="list-style-type: none"> <li>1. Make sure the valve is open as per the command</li> <li>2. Make sure the outlet temperature sensor is functioning properly.</li> </ol>

			<p>3. Make sure there is enough water supplied to the unit. If it requires adjust the "Air out temperature set point" in Control – Temperature Screen</p> <p>4. If above points are ok then press the Alarm Ack button in HMI.</p>
A31	Water Leakage Fault	Leakage sensor detects the water leak	<p>1. Water leakage fault is optional; it detects the fault when leakage sensor enabled</p> <p>2. Make sure there is not any water leakage.</p> <p>3. Is there any leakage found fixed it.</p> <p>4. If it requires adjusting the leakage fault delay or notifications cycle in factory settings screen.</p> <p>5. If above points are ok then press the Alarm Ack button in HMI.</p>
A32	Fan1 Threshold Value Not in Range	If the fan1 run command and actual running feedback is not in the threshold set value, then this fault occurs	<p>1. Make sure the fan1 is in running condition.</p> <p>2. Make sure the fan1 running feedback and run command are within threshold setting range.</p> <p>3. If it requires adjusting the fan speed threshold value in alarm settings screen.</p> <p>4. If above points are ok then press the Alarm Ack button in HMI.</p>
A33	Fan2 Threshold Value Not in Range	If the fan2 run command and actual running feedback is not in the threshold set value, then this fault occurs	<p>1. Make sure the fan2 is in running condition.</p> <p>2. Make sure the fan2 running feedback and run command are within threshold setting range.</p> <p>3. If it requires adjusting the fan speed threshold value in alarm settings screen.</p> <p>4. If above points are ok then press the Alarm Ack button in HMI.</p>

A34	Fan3 Threshold Value Not in Range	If the fan3 run command and actual running feedback is not in the threshold set value, then this fault occurs	<ol style="list-style-type: none"> <li>1. Make sure the fan3 is in running condition.</li> <li>2. Make sure the fan3 running feedback and run command are within threshold setting range.</li> <li>3. If it requires adjusting the fan speed threshold value in alarm settings screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A35	Fan4 Threshold Value Not in Range	If the fan4 run command and actual running feedback is not in the threshold set value, then this fault occurs	<ol style="list-style-type: none"> <li>1. Make sure the fan4 is in running condition.</li> <li>2. Make sure the fan4 running feedback and run command are within threshold setting range.</li> <li>3. If it requires adjusting the fan speed threshold value in alarm settings screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A36	Fan5 Threshold Value Not in Range	If the fan5 run command and actual running feedback is not in the threshold set value, then this fault occurs	<ol style="list-style-type: none"> <li>1. Make sure the fan5 is in running condition.</li> <li>2. Make sure the fan5 running feedback and run command are within threshold setting range.</li> <li>3. If it requires adjusting the fan speed threshold value in alarm settings screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A37	Fan6 Threshold Value Not in Range	If the fan6 run command and actual running feedback is not in the threshold set value, then this fault occurs	<ol style="list-style-type: none"> <li>1. Make sure the fan6 is in running condition.</li> <li>2. Make sure the fan6 running feedback and run command are within threshold setting range.</li> <li>3. If it requires adjusting the fan speed threshold value in alarm settings screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>

A38	Valve Threshold Value Not in Range	If the valve open command and actual opening feedback is not in the threshold set value, then this fault occurs	<ol style="list-style-type: none"> <li>1. Make sure the valve is in healthy condition.</li> <li>2. Make sure the valve running feedback and running command are within threshold setting range.</li> <li>3. If it requires adjusting the valve fbk threshold value in alarm settings screen.</li> <li>4. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A39	In Water Temperature is High	1. Actual In water temperature is higher than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A40	In Water Temperature is Low	1. Actual In water temperature is lower than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A41	Out Water Temperature is Low	1. Actual Out water temperature is lower than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A42	Out Water Temperature is High	1. Actual Outlet water temperature is higher than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>

A43	Entering Water Flow High	1. Actual inlet water flow is higher than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A44	Entering Water Flow Low	1. Actual inlet water flow is lower than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A45	Leaving Water Pressure High	1. Actual outlet water pressure is higher than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A46	Leaving Water Pressure Low	1. Actual outlet water pressure is lower than the set value.	<ol style="list-style-type: none"> <li>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</li> <li>2. Make sure proper water flow is available.</li> <li>3. If above points are ok then press the Alarm Ack button in HMI.</li> </ol>
A47	Water Leakage Fault	1. Leakage sensor detects the water leak in unit	<ol style="list-style-type: none"> <li>1. Water leakage fault is optional; it detects the fault when leakage sensor enabled</li> <li>2. Make sure there is not any water leakage.</li> <li>3. Is there any leakage found fixed it.</li> <li>4. If it requires adjusting the leakage fault delay or notifications cycle in factory settings screen.</li> </ol>

A48	Water Leakage Fault (Critical)	<p>1. Leakage sensor detects the water leak in unit continuously</p>	<p>1. Make sure there is not any water leakage.</p> <p>2. Is there any leakage found fixed it.</p> <p>3. If it requires adjusting the leakage fault delay or notifications cycle in factory settings screen.</p>
A49	Water Leakage Fault (Very Critical)	<p>1. Leakage sensor detects the water leak in unit continuously final Warning.</p>	<p>1. Make sure there is not any water leakage.</p> <p>2. Is there any leakage found fixed it.</p> <p>3. If it requires adjusting the leakage fault delay or notifications cycle in factory settings screen.</p>
A50..A55	Fan "X" Node Address:" X" Conflict	<p>1. While replacing the Repaired fan when the running fan address is overlapping with new fan address.</p>	<p>1. Make sure the fan node address should not overlap</p> <p>2. If it same address disconnect the running fan until the new fan gets new address then re connect it</p>
A56	Dp Setpoint Not reached	<p>1. If the actual dP value does not meets the dP setpoint with in the time (A19) then this fault occurs.</p>	<p>1. Make sure the dP sensor powered on.</p> <p>2. fans are functioning as per the command setpoint.</p> <p>3. If it requires adjusting the dP Value Alarm Delay(A19) in Alarm settings screen.</p>
A57	dp Actual Value Low	<p>1. Actual dP value is lower than the set value.</p>	<p>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</p> <p>2. Make sure dP sensor powered on.</p> <p>3. If it requires adjusting the dP Actual Value Low in Alarm settings screen.</p> <p>4. If above points are ok then press the Alarm Ack button in HMI.</p>

A58	dP Actual Value High	<p>1. Actual dp value is higher than the set value.</p>	<p>1. Make sure the correct parameter set value in Alarm settings screen in HMI or Web UI.</p> <p>2. Make sure dp sensor powered on and the probes are properly aligned.</p> <p>3. If it requires adjusting the dp Actual Value high in Alarm settings screen.</p> <p>4. If above points are ok then press the Alarm Ack button in HMI.</p>
A59	dP Sensor Value Out of Range (Low)	<p>1. Actual dp sensor read value is lower than the set value.</p>	<p>1. Make sure dp sensor powered on and the probes are properly aligned.</p> <p>2. If it requires adjusting the dp Actual Value high in Alarm settings screen.</p> <p>3. If above points are ok then press the Alarm Ack button in HMI.</p>
A60	dP Sensor Value Out of Range (High)	<p>1. Actual dp sensor read value is higher than the set value.</p>	<p>1. Make sure dp sensor powered on and the probes are properly aligned.</p> <p>2. If it requires adjusting the dp Actual Value high in Alarm settings screen.</p> <p>3. If above points are ok then press the Alarm Ack button in HMI.</p>

## Faulty Modular Replacement

### Fan Modular Replacement

- Rotate the fixing buckle to the left, pull the handle, and remove the fan module from the door.




Figure 153. Fan Module Removal

#### **⚠️ ⚠️ WARNING**

##### **SHOCK HAZARD**

- CAUTION: Double pole, neutral fusing. Disconnect mains before servicing.  
(ATTENTION. Double pôle/fusible sur le neutre. Débrancher l'alimentation avant l'entretien.)
- Arc flash and electric shock hazard. Can cause serious injury or death. Disconnect all local and remote electric power supplies before connecting.
- Installation, service, and maintenance work must be performed only by qualified personnel.
- Disconnect the device of the RDHx is the plug, and the output socket is easily accessible.

***Failure to follow these instructions can result in serious injury, death, or equipment damage.***

- The module supports hot swapping without power off, but please do not touch the contact interface.




Figure 154. Shock Attention

- Push the new fan module into the slot, observe the positioning circular hole at the buckle, and when they are concentric, press the buckle to fix the fan module.





Figure 155. New Fan Module Installation

- Rewrite the address of the fan.

Each time you insert only one replacement fan, by HMI to modify the fan address.



**Figure 156. Fan Node Address Rewrite**

- In case of any failure or modification on the fan, this screen helps to enable communication between the fan and controller.
- Generally, fan communication node starts from 2 to 7 from top to bottom.

If it is a new fan (Default address is 247) follow the following Steps


- 1. Place the fan into the unit
- 2. Enter the required fan address (PM4)
- 3. Press the Fan address confirm button (PM5) once the fan address updates the confirmation button will become initial position (No)
- 4. Disconnect the fan from the power for 30 seconds, LED on the fan will become off then connect the fan to the power

If the fan is old one and it's having the existing address of (2...7) any, follow below steps

- Place the fan into the unit.
- Enter the fan address (PM6) that needs to be restore default settings.
- Press the Fan address confirms button (PM7) once the fan address updates the confirmation button will become initial position (No)
- Disconnect the fan from the power for 30 seconds, LED on the fan will become off then connect the fan to the power
- Now the fan goes to default settings.
- Follow Method 1.


## Control Box Replacement Guide

- Use a small flathead screwdriver to remove the fixing screws on the green sockets and unplug all sockets. Unplug the 3 power cords.




**Figure 157. Screws and Plugs Removal**

- Loose the Thumb screws and pull out the control box.



**Figure 158. Control Box Removal**

- Push the new control box in and tighten the Thumb screw to fix the control box. And reconnect all the sockets.



**Figure 159. New Control Box Installation**

## Temperature Sensor Replacement Guide

The **RDHx** must be powered off before replacing a faulty temperature sensor.





Figure 160. Air in Temperature Sensor Diagram

Table 15. Control Box Temperature Sensor Connection Ports

Terminal	Wire Core Colour	Description
J2	Pin 5	White
	Pin 6	Black
	Pin 7	White
	Pin 8	White
	Pin 9	White
	Pin 10	White
	Pin 11	White
	Pin 12	Black


- 1) Replace air in temperature or room temperature sensors steps.
  - Use a small flathead screwdriver to remove the fixing screws on the green sockets of the J2 terminal from the power panel and pull it out.



**Figure 161. J2 Terminal Removal**


- Remove the faulty air in temperature or room temperature sensors cable from the J2 terminal ports.
- Replace the new temperature sensor connection to the J2 terminal ports.
- Secure the sensor cable with ties.

- 2) Replacement air out temperature sensor steps.
  - Use a small flathead screwdriver to loosen the fixing screws on the green sockets of the J2 terminal and pull the cable out.
  - Replace the new temperature sensor connection to the J2 terminal ports.
  - Remove the mounting screws and take off the sensor protection cover




**Figure 162. Remove sensor protection cover**

- Cut and remove the original temperature sensor



**Figure 163. Remove temperature sensor**

- Route new sensor cable along the fan cover to the sensor holder position and tie the cable properly.



**Figure 164. Route the sensor cable**

- Insert the new temperature sensor into the silicon holder and tie the cable to the bracket properly.




Figure 166. Holder the new sensor

- Fix the protection cover back to RDHx to secure the silicon sensor holder.




Figure 167. Fix the protection cover

## Differential Pressure Sensor Replacement Guide

- Remove the air pipe from DP sensor




Figure 168. Remove air pipe

- Disconnect the wires from DP sensor





Figure 169. Disconnect the wires from DP sensor

- Remove 2 mounting screws and take off the DP sensor



**Figure 170. Remove the DP sensor**

- Fix a new DP sensor with screws, connect the air pipe and wiring properly.

## Disconnect the network cable


- \* For the RDHx without gateway module, remove the network cable follow the instruction below:
- \* For the RDHx with gateway module, follow the instruction on page 137.

➤ Unplug the network cable carefully.




**Figure 171. Unplug the network cable**

➤ Remove and unlock the cable grommet, pull out the network cable from metal cutout.



**Figure 172. Pull out network cable**

- Cut the cable tie and remove the network cable; Re-secure other cables with cable tie if necessary.



**Figure 173. Remove network cable**

\* For the RDHx with gat way module, no need remove the entire cable, just unplug the connector from gat way to make sure the network cable stop work.

- Remove 2 mounting screws and take off the gat way metal cover from RDHx.




Figure 174. Remove metal cover

- Unplug the connector from gat way module.



Figure 175. Unplug the connector from gat way module

- Fix the metal cover back to the RDHx.

## LED Light Replacement Guide

### Tool & Material List




Figure 176. Tool List

- Open the fan cover.





Figure 177. Fan Cover Open

➤

- Use the scissor to shear the cable tie, unplug the male and female connectors.




**Figure 178. Unplug Connectors**

- Remove the two screws and take off the Led light module.



**Figure 179. LED Light Module Removal**


- Plug the new Led light module male connector into the female connector, tighten the two screws to install the new Led light module, use the cable tie to fix the connector. Close the fan cover.



**Figure 180. New LED Light Module Installation**

## Fan Cover Replacement Guide


### Tool & Material List



Scissors



Cable tie




Needle Nose Pliers



New Fan Cover

**Figure 181. Tool List**

- Open the fan cover.



**Figure 182. Fan Cover Open**

- Use the scissors to shear the cable ties.




Figure 183. Cable Ties Shearing

- Unplug the male and female connector. Refer to the last chapter to remove the LED modular and keep the LED modular.






Figure 184. Unplug Connectors

- Use the needle nose pliers to uninstall the circlip, then pull out both top and bottom the hinge pin. Remove the fan cover.



**Figure 185. Fan Cover Removal**

- According to the disassembly steps, install the LED modular and install the new fan cover. Then close it.



**Figure 186. LED Modular and Fan Cover Installation**




## Coil Replacement Guide


### Tool & Material List



Electric Screwdriver




PH2 Phillips Screwdriver Bit



Scissor



Cable Tie



New Coil

Figure 187. Tool List

- Place the RDHx on the ground.

### NOTICE

- Make sure EPE or other materials have been used as a cushion to protect the fan cover surface.

***Failure to follow these instructions can result in equipment damage.***






Figure 188. RDHx Placement

- Open the interface frame and disconnect the male hinge pin (on the frame) and female hinge (on the door), then remove the interface frame.




**Figure 189. Interface Frame Removal**

- Remove the temperature sensor, power cord, water leakage cord and actuator LR24A-MOD connection cable.




**Figure 190. Accessories Removal**

- Remove the Liquid Circuit Protection module and electric cable protection module.




**Figure 191. Protection Modules Removal**

- Remove the bottom fixing bracket.




**Figure 192. Bottom Fixing Bracket Removal**

- Remove the screws, then take coil left windshield off. (skip this step if there is no windshield).




**Figure 193. Coil Left Windshield Removal**

- Remove the left fixing screws.




**Figure 194. Left Fixing Screws Removal**

- Remove the hose cover.




**Figure 195. Hose Cover Removal**

- Remove the right L bracket.




**Figure 196. Right L Bracket Removal**

- Remove the right cover bracket.




**Figure 197. Right Cover Bracket Removal**

- Remove the right Z bracket.




**Figure 198. Right Z Bracket Removal**

- Remove the right fixing bracket.




**Figure 199. Right Fixing Bracket Removal**

- Remove the coil from the door.




**Figure 200. Coil Removal**

- Remove the coil protection grating and coil elbow protection plates.



**Figure 201. Protection Plates and Protection Grating Removal**

- Remove the screws.



**Figure 202. Screw Removal**

➤ Position the heat exchanger vertically on its side and remove its bottom and top cover plates.








Figure 203. Cover Plates Removal

➤ According to the disassembly steps, install the coil back to the RDHx.









**Figure 204. Coil Back Installation Process**